


12. EXPLODED VIEWS AND PARTS LIST


12-1. Indoor Unit (E-Parts Assy)



Location No.	Part No.	Description
401	43T60365	TERMINAL BLOCK; 3P
403	43T69319	TEMPERATURE SENSOR
404	43T69320	TEMPERATURE SENSOR

Location No.	Part No.	Description
405	43T69612	PC BOARD ASSY ;WRS-LED
410	43T62003	CORD CLAMP
411	43T69629	ASM-PCB-SERV

12-2. Indoor Unit



Location No.	Part No.	Description
201	43T00480	FRONT PANEL ASSY
202	43T09429	GRILLE OF AIR INLET (ORIGINAL,WHITE)
202	43T09431	GRILLE OF AIR INLET (42NQV009S-PANEL)
203	43T03357	BACK BODY ASSY
204	43T80317	AIR-FILTER
205	43T09392	HORIZONTAL LOUVER
206	43T70313	DRAIN HOSE
207	43T79301	CAP-DRAIN
208	43T21402	MOTOR; STEPPING
209	43T44387	REFRIGERATION CYCLE ASSY
210	43T47353	PIPE; SUCTION (RAS-13)
211	43T47355	PIPE; SUCTION (U1U2_GD)

Location No.	Part No.	Description
212	43T11319	PIPE SHIELD
213	43T19333	SENSOR FIX PLATE
217	43T22312	MOLD BEARING ASSEMBLY
218	43T39323	BEARING BASE
219	43T20323	ASSY CROSS FLOW FAN
220	43T39324	MOTOR BAND (LEFT)
221	43T39321	MOTOR BAND(RIGHT)
222	43T21393	FAN MOTOR
224	43T82309	INSTALLATION PLATE
225	43T69420	WIRELESS-REMOCO
226	43T63002	REMOTE CONTROL HOLDER
227	43T62326	TERMINAL COVER
228	43T60317	CORD MOTOR LOUVER
229	43T07311	PIPE HOLDER