



Exploded View


Indoor Unit



Outdoor Unit (7K Models)



Outdoor Unit (9K, 12K Models)



Replacement Parts List

Indoor Unit

LOCATION No.	DESCRIPTION		PART No.			REMARKS
			AS-H076PB/D/M/WL1	AS-H096PB/D/M/WL1	AS-H126PA/B/D/M/S/WL1	
131410	CHASSIS ASSEMBLY		3141A20004N	3141A20004D	3141A20004N	R
135311-1	GRILLE ASSEMBLY,DISCHARGE(INDOOR)		3531A20069G	3531A20069G	3531A20069G	R
135311-2	GRILLE ASSEMBLY,DISCHARGE(INDOOR)		3531A20069H	3531A20069H	3531A20069H	R
135311-3	GRILLE ASSEMBLY,DISCHARGE(INDOOR)		3531A20069J	3531A20069J	3531A20069J	R
135312	GRILLE ASSEMBLY,FRONT(INDOOR)	GOGH	-	-	3531A20248A	R
		BLUE	3531A20213E	3531A20213E	3531A20213E	R
		WOOD	3531A20213G	3531A20213G	3531A20213G	R
		METAL	3531A20213F	3531A20213F	3531A20213F	R
		SISLEY	-	-	3531A20248C	R
		WHITE	3531A20213H	3531A20213H	3531A20213H	R
135314	GRILLE ASSEMBLY,INLET	GOGH	-	-	3531A20147S	R
		BLUE	3531A20212F	3531A20212E	3531A20212E	R
		WOOD	3531A20212G	3531A20212G	3531A20212G	R
		METAL	3531A20212F	3531A20212F	3531A20212F	R
		SISLEY	-	-	3531A20147R	R
		WHITE	3531A20212C	3531A20212C	3531A20212C	R
135500-1	COVER		3550A20123A	3550A20123A	3550A20123A	R
135500-2	COVER		*	*	3550A20124A	R
135500-3	COVER		3550A20060A	3550A20060A	3550A20060A	R
135515	COVER ASSEMBLY, TOP(INDOOR)		3551A20031B	3551A20031B	3551A20031B	R
146811	MOTOR ASSEMBLY,STEP		4681A20055A	4681A20055A	4681A20055A	R
147581	LOUVER,HORIZONTAL		4758A20014B	4758A20014B	4758A20014B	R
152302	FILTER(MECH),A/C		5230A20032A	5230A20032A	5230A20032A	R
159830	AIR CLEANER ASSEMBLY		5983A20007F	5983A20007F	5983A20007F	R
249951	CONTROL BOX ASSEMBLY,INDOOR		4995A20372Q	4995A20372E	4995A20372A	R
263230	THERMISTOR ASSEMBLY		6323A20004N	6323A20004N	6323A20004N	R
264110	POWER CORD ASSEMBLY		6411A20014S	6411A20014S	6411A20014S	R
267110	REMOTE CONTROLLER ASSEMBLY		6711A20073Z	6711A20073Z	6711A20073Z	R
268712	PWB(PCB) ASSEMBLY,DISPLAY		6871A20462A	6871A20462A	6871A20462A	R
268714-1	PWB(PCB) ASSEMBLY,MAIN		6871A10121A	6871A10121A	6871A10121A	R
268714-2	PWB(PCB) ASSEMBLY,MAIN(DC)		6871A20439J	6871A20439D	6871A20439C	R
268717	PWB(PCB) ASSEMBLY,SUB		6871A20363D	6871A20363D	6871A20363D	R
330870	DRAIN PAN ASSEMBLY		3087A30004A	3087A30004A	3087A30004A	R
346810	MOTOR ASSEMBLY,INDOOR		4681A20091A	4681A20091A	4681A20091A	R
352115	TUBE ASSEMBLY,EVAPORATOR IN		*	*	5211A20302B	R
352116	TUBE ASSEMBLY,EVAPORATOR OUT		*	*	5211A20301B	R
35211B	TUBE ASSY,TUBING		5211AR7066F	5211AR7066F	5211AR7066D	R
352150	HOSE ASSEMBLY,DRAIN		5251AR1222R	5251AR1222R	5251AR1222R	R
352380	AIR GUIDE		5238A20020A	5238A20020A	5238A20020A	R
354210	EVAPORATOR ASSEMBLY,FIRST		5421A20072A	5421A20072A	5421A20072A	R
359012	FAN,TURBO		5900A00003A	5900A00003A	5900A00003A	R

NOTE) *Please ensure GCSC since these parts may be changed depending upon the buyer's request.
(GCSC WEBSITE <http://biz@LGservice.com>)

Replacement Parts List

LOCATION No.	DESCRIPTION		PART No.				REMARKS
			AS-H126PA/B/D/MS/WG1	LS-C126PB/D/M/WL1	LS-C096PB/D/ML1	LS-H076PB/D/M/WL1	
131410	CHASSIS ASSEMBLY		3141A20004N	3141A20004D	3141A20004D	3141A20004D	R
135311-1	GRILLE ASSEMBLY,DISCHARGE(INDOOR)		3531A20069G	3531A20069G	3531A20069G	3531A20069G	R
135311-2	GRILLE ASSEMBLY,DISCHARGE(INDOOR)		3531A20069H	3531A20069H	3531A20069H	3531A20069H	R
135311-3	GRILLE ASSEMBLY,DISCHARGE(INDOOR)		3531A20069J	3531A20069J	3531A20069J	3531A20069J	R
135312	GRILLE ASSEMBLY,FRONT(INDOOR)	GOGH	3531A20248A	-	-	-	R
		BLUE	3531A20213E	3531A20213K	3531A20213K	3531A20213E	R
		WOOD	3531A20213G	3531A20213M	3531A20213M	3531A20213G	R
		METAL	3531A20213F	3531A20213L	3531A20213L	3531A20213F	R
		SISLEY	3531A20248C	-	-	-	R
		WHITE	3531A20213H	3531A20213J	-	-	R
135314	GRILLE ASSEMBLY,INLET	GOGH	3531A20147S	-	-	-	R
		BLUE	3531A20212E	3531A20212E	3531A20212E	3531A20212E	R
		WOOD	3531A20212G	3531A20212G	3531A20212G	3531A20212G	R
		METAL	3531A20212F	3531A20212F	3531A20212F	3531A20212F	R
		SISLEY	3531A20147R	-	-	-	R
		WHITE	3531A20212C	3531A20212C	-	-	R
135500-1	COVER		3550A20123A	3550A20123A	3550A20123A	3550A20123A	R
135500-2	COVER		3550A20124A	3550A20124A	3550A20124A	3550A20124A	R
135500-3	COVER		3550A20060A	3550A20060A	3550A20060A	3550A20060A	R
135515	COVER ASSEMBLY,TOP(INDOOR)		3551A20031B	3551A20031B	3551A20031B	3551A20031B	R
146811	MOTOR ASSEMBLY,STEP		4681A20055A	4681A20055A	4681A20055A	4681A20055A	R
147581	LOUVER,HORIZONTAL		4758A20014B	4758A20014B	4758A20014B	4758A20014B	R
152302	FILTER(MECH),A/C		5230A20032A	5230A20032A	5230A20032A	5230A20032A	R
159830	AIR CLEANER ASSEMBLY		5983A20007F	5983A20007F	5983A20007K	5983A20007H	R
249951	CONTROL BOX ASSEMBLY,INDOOR		4995A20372A	4995A20372B	4995A20434E	4995A20372Q	R
263230	THERMISTOR ASSEMBLY		6323A20004N	6323A20004N	6323A20004N	6323A20004N	R
264110	POWER CORD ASSEMBLY		6411A20014S	6411A20014S	6411A20043D	6411A20014S	R
266090	H.V ASSEMBLY		-	6609A10003S	6609A10003S	6609A10003S	R
267110	REMOTE CONTROLLER ASSEMBLY		6711A20073Z	6711A20073E	6711A20073E	6711A20073Z	R
268712	PWB(PCB) ASSEMBLY,DISPLAY		6871A20462A	6871A20462B	6871A20462B	6871A20462A	R
268714-1	PWB(PCB) ASSEMBLY,MAIN		6871A10121A	6871A10121B	6871A10121B	6871A10121A	R
268714-2	PWB(PCB) ASSEMBLY,MAIN(DC)		6871A20439C	6871A20439A	6871A20439E	6871A20439J	R
268717	PWB(PCB) ASSEMBLY,SUB		6871A20363D	6871A20259B	6871A20259B	6871A20363D	R
330870	DRAIN PAN ASSEMBLY		3087A30004A	3087A30004A	3087A30004A	3087A30004A	R
346810	MOTOR ASSEMBLY,INDOOR		4681A20091A	4681A20091A	4681A20091A	4681A20091A	R
352115	TUBE ASSEMBLY,EVAPORATOR IN		5211A20302B	5211A20302A	5211A20302B	5211A20302B	R
352116	TUBE ASSEMBLY,EVAPORATOR OUT		5211A20301B	5211A20301C	5211A20301C	5211A20301B	R
35211B	TUBE ASSY,TUBING		5211AR7066D	5211AR7066D	5211AR7066F	5211AR7066F	R
352150	HOSE ASSEMBLY,DRAIN		5251AR1222R	5251AR1222R	5251AR1222R	5251AR1222R	R
352380	AIR GUIDE		5238A20020A	5238A20020A	5238A20020A	5238A20020A	R
354210	EVAPORATOR ASSEMBLY,FIRST		5421A20072A	5421A20072B	5421A20072A	5421A20072A	R
359012	FAN,TURBO		5900A00003A	5900A00003A	5900A00003A	5900A00003A	R

LOCATION No.	DESCRIPTION	PART No.		REMARKS
		LS-C126PKL1	LS-C126PQL1	
131410	CHASSIS ASSEMBLY	3141A20004D	3141A20004D	R
135311-1	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A20069G	3531A20069G	R
135311-2	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A20069H	3531A20069H	R
135311-3	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A20069J	3531A20069J	R
135312	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A20248T	3531A20248U	R
135500-1	COVER	3550A20123A	3550A20123A	R
135500-2	COVER	3550A20124A	3550A20124A	R
135500-3	COVER	3550A20060A	3550A20060A	R
135515	COVER ASSEMBLY, TOP(INDOOR)	3551A20031B	3551A20031B	R
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	R
147581	LOUVER,HORIZONTAL	4758A20014B	4758A20014B	R
159830	AIR CLEANER ASSEMBLY	5983A20007F	5983A20007F	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A20372B	4995A20372B	R
263230	THERMISTOR ASSEMBLY	6323A20004N	6323A20004N	R
264110	POWER CORD ASSEMBLY	6411A20014S	6411A20014S	R
266090	H.V ASSEMBLY	6609A10003S	6609A10003S	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20073E	6711A20073E	R
268714-1	PWB(PCB) ASSEMBLY,MAIN	6871A10121B	6871A10121B	R
268714-2	PWB(PCB) ASSEMBLY,MAIN(DC)	6871A20439A	6871A20439A	R
330870	DRAIN PAN ASSEMBLY	3087A30004A	3087A30004A	R
346810	MOTOR ASSEMBLY,INDOOR	4681A20091A	4681A20091A	R
352115	TUBE ASSY,EVAPORATOR IN	5211A20302A	5211A20302A	R
352116	TUBE ASSEMBLY,EVAPORATOR OUT	5211A20301C	5211A20301C	R
35211B	TUBE ASSY,TUBING	5211AR7066D	5211AR7066D	R
352150	HOSE ASSEMBLY,DRAIN	5251AR1222R	5251AR1222R	R
352380	AIR GUIDE	5238A20020A	5238A20020A	R
354210	EVAPORATOR ASSEMBLY,FIRST	5421A20072B	5421A20072B	R
359012	FAN,TURBO	5900A00003A	5900A00003A	R

Replacement Parts List

LOCATION No.	DESCRIPTION		PART No.		REMARKS
			LS-H096PA/B/D/M/S/WL1	LS-H126PAB/D/M/S/WL1	
131410	CHASSIS ASSEMBLY		3141A20004D	3141A20004D	R
135311-1	GRILLE ASSEMBLY,DISCHARGE(INDOOR)		3531A20069G	3531A20069G	R
135311-2	GRILLE ASSEMBLY,DISCHARGE(INDOOR)		3531A20069H	3531A20069H	R
135311-3	GRILLE ASSEMBLY,DISCHARGE(INDOOR)		3531A20069J	3531A20069J	R
135312	GRILLE ASSEMBLY,FRONT(INDOOR)	GHGH	3531A20248A	3531A20248A	R
		BLUE	3531A20213E	3531A20213E	R
		WOOD	3531A20213G	3531A20213G	R
		METAL	3531A20213F	3531A20213F	R
		SISLEY	3531A20248C	3531A20248C	R
		WHITE	3531A20213H	3531A20213H	R
135314	GRILLE ASSEMBLY,INLET	GOGH	3531A20147S	3531A20147S	R
		BLUE	3531A20212E	3531A20212E	R
		WOOD	3531A20212G	3531A20212G	R
		METAL	3531A20212F	3531A20212F	R
		SISLEY	3531A20147R	3531A20147R	R
		WHITE	3531A20212C	3531A20212C	R
135500-1	COVER		3550A20123A	3550A20123A	R
135500-2	COVER		3550A20124A	3550A20124A	R
135500-3	COVER		3550A20060A	3550A20060A	R
135515	COVER ASSEMBLY, TOP(INDOOR)		3551A20031B	3551A20031B	R
146811	MOTOR ASSEMBLY,STEP		4681A20055A	4681A20055A	R
147581	LOUVER,HORIZONTAL		4758A20014B	4758A20014B	R
152302	FILTER(MECH),A/C		5230A20032A	5230A20032A	R
159830	AIR CLEANER ASSEMBLY		5983A20007H	5983A20007H	R
249951	CONTROL BOX ASSEMBLY,INDOOR		4995A20372E	4995A20372A	R
263230	THERMISTOR ASSEMBLY		6323A20004N	6323A20004N	R
264110	POWER CORD ASSEMBLY		6411A20014S	6411A20014S	R
266090	H.V ASSEMBLY		6609A10003S	6609A10003S	R
267110	REMOTE CONTROLLER ASSEMBLY		6711A20073Z	6711A20073Z	R
268712	PWB(PCB) ASSEMBLY,DISPLAY		6871A20462A	6871A20462A	R
268714-1	PWB(PCB) ASSEMBLY,MAIN		6871A10121A	6871A10121A	R
268714-2	PWB(PCB) ASSEMBLY,MAIN(DC)		6871A20439D	6871A20439C	R
268717	PWB(PCB) ASSEMBLY,SUB		6871A20363D	6871A20363D	R
330870	DRAIN PAN ASSEMBLY		3087A30004A	3087A30004A	R
346810	MOTOR ASSEMBLY,INDOOR		4681A20091A	4681A20091A	R
352115	TUBE ASSEMBLY,EVAPORATOR IN		5211A20302B	5211A20302A	R
352116	TUBE ASSEMBLY,EVAPORATOR OUT		5211A20301B	5211A20301B	R
35211B	TUBE ASSY,TUBING		5211AR7066F	5211AR7066D	R
352150	HOSE ASSEMBLY,DRAIN		5251AR1222R	5251AR1222R	R
352380	AIR GUIDE		5238A20020A	5238A20020A	R
354210	EVAPORATOR ASSEMBLY,FIRST		5421A20072A	5421A20072A	R
359012	FAN,TURBO		5900A00003A	5900A00003A	R

LOCATION No.	DESCRIPTION	PART No.			REMARKS
		LSNH096PBL1.ABLALTA	LSNH096PSL1.APXALTA	LSNH096PEL1.ASMALTA	
131410	CHASSIS ASSEMBLY	3141A20004D	3141A20004D	3141A20004D	R
135311-1	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A20069G	3531A20069G	3531A20069G	R
135311-2	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A20069H	3531A20069H	3531A20069H	R
135311-3	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A20069J	3531A20069J	3531A20069J	R
135312	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A20248R	3531A20248S	3531A20248V	R
135314	GRILLE ASSEMBLY,INLET	3531A20212Y	3531A20147H	3531A20273A	R
135500-1	COVER	3550A20123A	3550A20123A	3550A20123A	R
135500-2	COVER	3550A20124A	3550A20124A	3550A20124A	R
135500-3	COVER	3550A20060A	3550A20060A	3550A20060A	R
135515	COVER ASSEMBLY, TOP(INDOOR)	3551A20031B	3551A20031B	3551A20031B	R
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	4681A20055A	R
147581	LOUVER,HORIZONTAL	4758A20014B	4758A20014B	4758A20014B	R
152302	FILTER(MECH),A/C	5230A20032A	5230A20032A	5230A20032A	R
159830	AIR CLEANER ASSEMBLY	5983A20007S	5983A20007S	5983A20007S	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A20434C	4995A20434C	4995A20434C	R
263230	THERMISTOR ASSEMBLY	6323A20004N	6323A20004N	6323A20004N	R
264110	POWER CORD ASSEMBLY	6411A20016H	6411A20016H	6411A20016H	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20104A	6711A20104A	6711A20104A	R
268712	PWB(PCB) ASSEMBLY,DISPLAY	6871A20462A	6871A20462A	6871A20462A	R
268714-1	PWB(PCB) ASSEMBLY,MAIN	6871A10121A	6871A10121A	6871A10121A	R
268714-2	PWB(PCB) ASSEMBLY,MAIN(DC)	6871A20439D	6871A20439D	6871A20439D	R
268717	PWB(PCB) ASSEMBLY,SUB	6871A20363D	6871A20363D	6871A20363D	R
330870	DRAIN PAN ASSEMBLY	3087A30004A	3087A30004A	3087A30004A	R
346810	MOTOR ASSEMBLY,INDOOR	4681A20091A	4681A20091A	4681A20091A	R
352115	TUBE ASSEMBLY,EVAPORATOR IN	5211A20302A	5211A20302A	5211A20302A	R
352116	TUBE ASSEMBLY,EVAPORATOR OUT	5211A20301B	5211A20301B	5211A20301B	R
35211B	TUBE ASSEMBLY,TUBING	5211AR7066F	5211AR7066F	5211AR7066F	R
352150	HOSE ASSEMBLY,DRAIN	5251AR1222R	5251AR1222R	5251AR1222R	R
352380	AIR GUIDE	5238A20020A	5238A20020A	5238A20020A	R
354210	EVAPORATOR ASSEMBLY,FIRST	5421A20072A	5421A20072A	5421A20072A	R
359012	FAN,TURBO	5900A00003A	5900A00003A	5900A00003A	R

LOCATION No.	DESCRIPTION	PART No.		REMARKS
		LS-H121PDL2.AWDBLAT	LS-H121PDL3	
131410	CHASSIS ASSEMBLY	3141A20030A	3141A20030C	R
135314	GRILLE ASSEMBLY,INLET	3531A20278C	3531A20277E	R
135312	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A20277E	3531A20278C	R
135500-1	COVER	3550A20123C	3550A20123C	R
135500-2	COVER	3550A20124B	3550A20124B	R
135500-3	COVER	3550A20060A	3550A20060A	R
135515	COVER ASSEMBLY, TOP(INDOOR)	3551A20031F	3551A20031H	R
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	R
147581	LOUVER,HORIZONTAL	4758A20014B	4758A20014B	R
159830	AIR CLEANER ASSEMBLY	5983A20007U	5983A20007U	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A20487E	4995A20487F	R
263230	THERMISTOR ASSEMBLY	6323A20004N	6323A20004N	R
264110	POWER CORD ASSEMBLY	6411A20015M	6411A20026N	R
266090	H.V ASSEMBLY	6609A10008A	6609A10008A	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A90031Z	6711A90031Z	R
268712	PWB(PCB) ASSEMBLY,DISPLAY	6871A20462A	6871A20462A	R
268714-1	PWB(PCB) ASSEMBLY,MAIN(AC)	6871A10121N	6871A10121N	R
268714-2	PWB(PCB) ASSEMBLY,MAIN(DC)	6871A20439T	6871A20439T	R
330870	DRAIN PAN ASSEMBLY	3087A30004A	3087A30004A	R
346810	MOTOR ASSEMBLY,INDOOR	4681A20091F	4681A20091A	R
352115	TUBE ASSEMBLY,EVAPORATOR IN	5211A20302B	5211A20302B	R
352116	TUBE ASSEMBLY,EVAPORATOR OUT	5211A20301B	5211A20301A	R
35211B	TUBE ASSEMBLY,TUBING	5211AR7066D	5211AR7066D	R
352150	HOSE ASSEMBLY,DRAIN	5251AR1222R	5251AR1222R	R
352380	AIR GUIDE	5238A20034A	5238A20034A	R
354210	EVAPORATOR ASSEMBLY,FIRST	5421A20072A	5421A20072A	R
359012	FAN,TURBO	5900A00003A	5900A00003A	R
668713	PWB(PCB) ASSEMBLY,SUB	6871A20363F	6871A20363F	R

Outdoor Unit

LOCATION No.	DESCRIPTION	PART No.			REMARKS
		AS-H076PB/D/M/WL1	AS-H096PB/D/M/WL1	AS-H126PA/B/D/M/S/WL1	
430410	BASE ASSY,OUTDOOR	3041A20016A	3041A20008K	3041A20008K	R
435301	GRILLE,DISCHARGE	*	3530A20006B	3530A20006B	R
435511	COVER ASSEMBLY,CONTROL(OUTDOOR)	3551A30023Q	3551A30023E	3551A30023E	R
437210	PANEL ASSEMBLY,FRONT(OUTDOOR)	3720A10171A	3721A20027P	3721A20027P	R
437212	PANEL ASSY,REAR(OUTDOOR)	3720A10172A	3721A20026B	3721A20026A	R
447910	BARRIER ASSEMBLY,OUTDOOR	4790A10025B	4791A30002A	4791A30002A	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681A20121A	4681A20004S	4681A20004S	R
549610	MOUNT,MOTOR	4960A10013A	4960A10002A	4960A10002A	R
550140	ISOLATOR,COMP	4H00982E	*	4H00982E	R
552111	TUBE ASSEMBLY,CAPILLARY	5211A21121B	5211A30331Q	5211A20117J	R
552116	TUBE ASSEMBLY,REVERSING	5211A20188U	5211A20160E	5211A20140X	R
552201	VALVE,CHECK	5220AR7182A	5220AR7182A	5220AR7182A	R
552202	VALVE,REVERSING	5220AR3228D	5220AR3228B	5220AR3228D	R
552203-1	VALVE,SERVICE	2H02479P	2H02479H	2H02479H	R
552203-2	VALVE,SERVICE	5220A20001B	5220A20001B	5220A20006B	R
554031	CONDENSER ASSEMBLY,BENT	5403A20045M	5403A20019F	5403A20019V	R
554160	COMPRESSOR SET	2520UGDP2CA	2520UGAP2GA	2520UGHP2AA	R
559010	FAN ASSEMBLY,PROPELLER	5900AR1266A	5901A10004A	5901A10004A	R
561410	COIL ASSEMBLY,REVERSING VALVE	6141A20017A	3A02028Y	6141AR3733R	R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A10032B	4995A20083B	4995A20083Y	R
W0CZZ	CAPACITOR,DRAWING	6120AR2194H	6120AR2194N	2H01451T	R

NOTE) *Please ensure GCSC since these parts may be changed depending upon the buyer's request.
(GCSC WEBSITE <http://biz.LGservice.com>)

Replacement Parts List

LOCATION No.	DESCRIPTION	PART No.				REMARKS
		AS-H126PA/B/D/M/S/WG1	LS-C126PB/D/M/WL1	LS-C096PB/D/ML1	LS-H076PB/D/M/WL1	
430410	BASE ASSY,OUTDOOR	3041A20008L	3041A20008J	3041AR2415K	3041A20016A	R
435301	GRILLE,DISHARGE	3530A20006B	3530A20006B	-	3530A20006B	R
435511	COVER ASSEMBLY,CONTROL(OUTDOOR)	3551A30023E	3551A30023C	4994AR3492B	3551A30023Q	R
437210	PANEL ASSEMBLY,FRONT(OUTDOOR)	3721A20027B	3721A20027B	3531AR2512R	3720A10171A	R
437212	PANEL ASSY,REAR(OUTDOOR)	3721A20026A	3721A20026A	3530AR0058B	3720A10172A	R
447910	BARRIER ASSEMBLY,OUTDOOR	4791A30002A	4791A30002A	-	4791A20011A	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681A20004S	4681A20004S	4681A20121B	4681A20004F	R
549610	MOUNT,MOTOR	4960A10002A	4960A10002C	4810AR1287B	4960A10013A	R
550140	ISOLATOR,COMP	4H00982E	4H00982E	4H00982E	4H00982E	R
552111	TUBE ASSEMBLY,CAPILLARY	5211A20117J	5211A20133N	5211A30275D	5211A10402B	R
552116	TUBE ASSEMBLY,REVERSING	5211A20140X	-	-	5211A21027A	R
552201	VALVE,CHECK	5220AR7182A	-	-	3H01552C	R
552202	VALVE,REVERSING	5220AR3228D	-	5424AR3582H	5220AR3084A	R
552203-1	VALVE,SERVICE	2H02479H	2H02479H	2H02479F	2H02479H	R
552203-2	VALVE,SERVICE	5220A20006B	2H01890L	2A00393U	2A00393U	R
554031	CONDENSER ASSEMBLY,BENT	5403A20019V	5403A20026K	5403AR2870M	5403A20059F	R
554160	COMPRESSOR SET	2520UGHP2AA	5416A20008C	5416A20013L	2520UKYP2CA	R
559010	FAN ASSEMBLY,PROPELLER	5901A10004A	5901A10004A	5900AR1266A	5900AR1266A	R
561410	COIL ASSEMBLY,REVERSING VALVE	6141AR3733R	-	6750A30001C	3A02028Y	R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A20433B	4995A20083W	4995A20447D	4995A10032B	R
W0CZZ	CAPACITOR,DRAWING	2H01451T	2H01451T	2H01451P	6120AR2194H	

NOTE) *Please ensure GCSC since these parts may be changed depending upon the buyer's request.
(GCSC WEBSITE <http://biz.LGservice.com>)

LOCATION No.	DESCRIPTION	PART No.	REMARKS
		LS-C126PK/QL1	
430410	BASE ASSY,OUTDOOR	3041A20008J	R
435301	GRILLE,DISCHARGE	3530A20006B	R
435511	COVER ASSEMBLY,CONTROL(OUTDOOR)	3551A30023C	R
437210	PANEL ASSEMBLY,FRONT(OUTDOOR)	3721A20027P	R
437212	PANEL ASSEMBLY,REAR(OUTDOOR)	3721A20026A	R
447910	BARRIER ASSEMBLY,OUTDOOR	4791A30002A	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681A20004S	R
549610	MOUNT,MOTOR	4960A10002C	R
50140	ISOLATOR,COMP	4H00982E	R
552111	TUBE ASSEMBLY,CAPILLARY	5211A20133N	R
552203-1	VALVE,SERVICE	2H02479H	R
552203-2	VALVE,SERVICE	2H01890L	R
554031	CONDENSER ASSEMBLY,BENT	5403A20026K	R
554160	COMPRESSOR	5416A20008C	R
559010	FAN ASSEMBLY,PROPELLER	5901A10004A	R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A20083W	R
W0CZZ	CAPACITOR,DRAWING	2H01451T	R

NOTE) *Please ensure GCSC since these parts may be changed depending upon the buyer's request.
(GCSC WEBSITE <http://biz.LGservice.com>)

Replacement Parts List

LOCATION No.	DESCRIPTION	PART No.				REMARKS
		LS-H096PA/B/D M/SWL1	LS-H126PA/B/D M/SWL1	LS-H121PDL2. AWDBLAT	LSUH121PUL3	
430410	BASE ASSY,OUTDOOR	3041A20008K	3041A20008K	3041A20008K	3041A20008K	R
435301	GRILLE,DISHARGE	3530A20006B	3530A20006B	3530A20006G	3530A20006G	R
435511	COVER ASSEMBLY,CONTROL(OUTDOOR)	3551A30023E	3551A30058D	3551A30023W	3551A30023W	R
437210	PANEL ASSEMBLY,FRONT(OUTDOOR)	3721A20027A	3721A20027B	3721A20027T	3721A20027T	R
437212	PANEL ASSY,REAR(OUTDOOR)	3721A20026B	3721A20026B	3721A20026K	3721A20026K	R
447910	BARRIER ASSEMBLY,OUTDOOR	4791A30002B	4791A30002A	4791A30002A	4791A30002A	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681A20004S	4681A20004S	4681A20004R	4681A20004R	R
549610	MOUNT,MOTOR	4960A10002A	4960A10002A	4960A10002A	-	R
550140	ISOLATOR,COMP	4H00982E	4H00982E	4H00982E	4H00982E	R
552111	TUBE ASSEMBLY,CAPILLARY	5211A20117G	5211A20141H	5211A20117L	5211A20117L	R
552116	TUBE ASSEMBLY,REVERSING	5211A20116D	5211A20140J	5211A20140Z	5211A20140Z	R
552201	VALVE,CHECK	3H01552F	3H01552F	3H01552F	3H01552F	R
552202	VALVE,REVERSING	5220AR3084A	5220AR3084A	5220AR3084B	5220AR3084B	R
552203-1	VALVE,SERVICE	2H02479H	5220A20005B	5220A20005B	5220A20005B	R
552203-2	VALVE,SERVICE	2A00393U	5220A20003B	5220A20003B	5220A20003B	R
554031	CONDENSER ASSEMBLY,BENT	5403A20026F	5403A20026F	5403A20019V	5403A20019V	R
554160	COMPRESSOR SET	5416A20013C	5416A20019A	2520UKWC2HA	2520UKWC2HA	R
559010	FAN ASSEMBLY,PROPELLER	5901A10004A	5901A10004A	5901A10055A	5901A10055A	R
561410	COIL ASSEMBLY,REVERSING VALVE	3A02028Y	3A02028Y	6141AR3851Y	6141AR3851Y	R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A20083F	4995A20083S	4995A20382A	4995A20382A	R
W0CZZ	CAPACITOR,DRAWING	2H01451P	2H01451P	0CZZA20001L	0CZZA20001L	R

NOTE) *Please ensure GCSC since these parts may be changed depending upon the buyer's request.
(GCSC WEBSITE <http://biz.LGservice.com>)