


Exploded View & Replacement Parts List

1. Indoor Unit

SQ/SR Chassis




Exploded View & Replacement Parts List

LOCATION No.	DESCRIPTION	PART No.							SVC CODE
		AMNH076LQL0	AMNC076LQL0	AMNH096LQL0	AMNH096LQA0	AMNC096LQL0	AMNH126LRL0	AMNC126LRL0	
131410	CHASSIS ASSEMBLY	3141A20006A	3141A20006A	3141A20006A	3141A20006A	3141A20006A	3141A20005A	3141A20005A	R
135311	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A10127A	3531A10127A	3531A10127A	3531A10127A	3531A10127A	3531A10230A	3531A10230A	R
135314	GRILLE ASSEMBLY,INLET SUB	3531A20100B	3531A20100A	3531A20100B	3531A20100B	3531A20100A	3531A10117B	3531A10117C	R
135316	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A20187M	3531A20187Q	3531A20187M	3531A20187E	3531A20187Q	3531A10208N	3531A10208Q	R
135516	COVER ASSEMBLY,MOTOR	3551A20050P	3551A20050P	3551A20050P	3551A20050P	3551A20050P	3551A20099A	3551A20099A	R
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	4681A20055A	4681A20055A	4681A20055A	4681A20055A	4681A20055A	R
152302	FILTER(MECH),A/C	5230A10005A	5230A10005A	5230A10005A	5230A10005A	5230A10005A	5230A20014A	5230A20014A	R
152313	FILTER ASSEMBLY,DEODORIZER	5231A20032C	5231A20032C	5231A20032C	-	5231A20032C	5231A20032C	5231A20032C	R
159830	AIR CLEANER ASSEMBLY	5983A10009V	5983A10009V	5983A10009V	-	5983A10009V	5983A10006T	5983A10006T	R
159901	VANE,HORIZONTAL	5990A10005A	5990A10005A	5990A10005A	5990A10005A	5990A10005A	5990A20007A	5990A20007A	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A20361A	4995A20361G	4995A20361B	4995A20361N	4995A20361H	4995A20361D	4995A20361J	R
263230-1	THERMISTOR ASSEMBLY	6323AQ3226T	6323AQ3226T	6323AQ3226T	6323AQ3226T	6323AQ3226T	6323AQ3226T	6323AQ3226T	R
263230-2	THERMISTOR ASSEMBLY	6323A20004A	6323A20004A	6323A20004A	6323A20004A	6323A20004A	6323A20004A	6323A20004A	R
266090	H.V ASSEMBLY	6609A10003J	6609A10003J	6609A10003J	-	6609A10003J	6609A10003H	6609A10003H	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20067J	6711A20067H	6711A20067J	6711A20083F	6711A20067H	6711A20067J	6711A20067H	R
268712	PWB(PCB) ASSEMBLY,DISPLAY	6871A20194A	6871A20194A	6871A20194A	6871A20194A	6871A20194A	6871A20390A	6871A20390A	R
268715	PWB(PCB) ASSEMBLY,MAIN(AC)	6871A20267B	6871A20267B	6871A20267B	6871A20267B	6871A20267B	6871A20267B	6871A20267B	R
268716	PWB(PCB) ASSEMBLY,MAIN(DC)	6871A20440A	6871A20440G	6871A20440B	6871A20440B	6871A20440H	6871A20440D	6871A20440K	R
342800	BEARING	4280A20004A	4280A20004A	4280A20004A	4280A20004A	4280A20004A	4280A20004A	4280A20004A	R
346810	MOTOR ASSEMBLY,INDOOR	4681A20062A	4681A20062A	4681A20062A	4681A20062A	4681A20062A	4681A20048A	4681A20048A	R
35211B	TUBE ASSEMBLY,TUBING	5211AR7066P	5211AR7066P	5211AR7066P	5211AR7066P	5211AR7066P	5211AR7066L	5211AR7066L	R
352115	TUBE ASSEMBLY,EVAPORATOR IN	5211A20470J	5211A20470J	5211A20470J	5211A20470J	5211A20470J	5211A20388H	5211A20388H	R
352116	TUBE ASSEMBLY,EVAPORATOR OUT	5211A20471D	5211A20471D	5211A20471D	5211A20471D	5211A20471D	5211A20389F	5211A20389F	R
352150	HOSE ASSEMBLY,DRAIN	5251AR2575F	5251AR2575F	5251AR2575F	5251AR2575F	5251AR2575F	5251AR2575F	5251AR2575F	R
354210	EVAPORATOR ASSEMBLY,FIRST	5421A10024A	5421A10024A	5421A10024A	5421A10024A	5421A10024A	5421A20086A	5421A20086A	R
359011	FAN ASSEMBLY,CROSS FLOW	5901A20007B	5901A20007B	5901A20007B	5901A20007B	5901A20007B	5901A20007A	5901A20007A	R
733010	PLATE ASSEMBLY,INSTALL	3301A10003A	3301A10003A	3301A10003A	3301A10003A	3301A10003A	1H00843A	1H00843A	R
W0CZZ	CAPACITOR,DRAWING	3H01487A	3H01487A	3H01487A	3H01487A	3H01487A	3H1487A	3H1487A	R


LOCATION No.	DESCRIPTION	PART No.			SVC CODE
		AMNH076PQL0	AMNH096PQL0	AMNH126PRL0	
131410	CHASSIS ASSEMBLY	3141A20006A	3141A20006A	3141A20005A	
135311	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A10127H	3531A10127H	3531A10107L	
135314	GRILLE ASSEMBLY,INLET SUB	3531A10277F	3531A10277F	3531A10276J	
135316	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A10275V	3531A10275V	3531A10274Z	
135516	COVER ASSEMBLY,MOTOR	3551A20050P	3551A20050P	3551A20099A	
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	4681A20055A	
152302	FILTER(MECH),A/C	5230A10005A	5230A10005A	5230A20014C	
152313	FILTER ASSEMBLY,DEODORIZER	5231A20032C	5231A20032C	5231A20032C	
159830	AIR CLEANER ASSEMBLY	5983A10009V	5983A10009V	5983A10006T	
159901	VANE,HORIZONTAL	5990A10005A	5990A10005A	5990A20007A	
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A11004F	4995A11004G	4995A11004H	
263230-1	THERMISTOR ASSEMBLY	6323AQ3226T	6323AQ3226T	6323AQ3226T	
263230-2	THERMISTOR ASSEMBLY	6323A20004A	6323A20004A	6323A20004A	
266090	H.V ASSEMBLY	6609A10003J	6609A10003J	6609A10003H	
267110	REMOTE CONTROLLER ASSEMBLY	6711A20067J	6711A20067J	6711A20067J	
268712	PWB(PCB) ASSEMBLY,DISPLAY	6871A20498A	6871A20498A	6871A20498B	
268715	PWB(PCB) ASSEMBLY,MAIN(AC)	6871A20267B	6871A20267B	6871A20267B	
268716	PWB(PCB) ASSEMBLY,MAIN(DC)	6871A20440A	6871A20440B	6871A20440D	
342800	BEARING	4280A20004A	4280A20004A	4280A20004A	
346810	MOTOR ASSEMBLY,INDOOR	4681A20062A	4681A20062A	4681A20048A	
35211B	TUBE ASSEMBLY,TUBING	5211A21399B	5211A21399B	5211A21400F	
352115	TUBE ASSEMBLY,EVAPORATOR IN	5211A20470J	5211A20470J	5211A20388H	
352116	TUBE ASSEMBLY,EVAPORATOR OUT	5211A20471D	5211A20471D	5211A20389F	
352150	HOSE ASSEMBLY,DRAIN	5251AR2575F	5251AR2575F	5251AR2575F	
354210	EVAPORATOR ASSEMBLY,FIRST	5421A10024A	5421A10024A	5421A20086A	
359011	FAN ASSEMBLY,CROSS FLOW	5901A20007B	5901A20007B	5901A20007A	
733010	PLATE ASSEMBLY,INSTALL	3301A10003A	3301A10003A	1H00843A	
W0CZZ	CAPACITOR,DRAWING	3H01487A	3H01487A	3H01487A	

ST Chassis



LOCATION No.	DESCRIPTION	PART No.					SVC CODE
		AMNH186LTLO	AMNC186LTLO	AMNH246LTLO	AMNH246LTA0	AMNC246LTLO	
131410	CHASSIS ASSEMBLY	3141A10002A	3141A10002A	3141A10002A	3141A10002A	3141A10002A	R
135311	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A10116A	3531A10116A	3531A10116A	3531A10116A	3531A10116A	R
135314	GRILLE ASSEMBLY,INLET SUB	3531A20107W	3531A20107V	3531A20107W	-	3531A20107V	R
135316	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A20207E	3531A20207F	3531A20207E	3531A24010F	3531A20207F	R
135516	COVER ASSEMBLY,MOTOR	3551A20099C	3551A20099C	3551A20099C	3551A20099C	3551A20099C	R
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	4681A20055A	4681A20055A	4681A20055A	R
152302	FILTER(MECH),A/C	5230A20001A	5230A20001A	5230A20001A	5230A20001A	5230A20001A	R
159830	AIR CLEANER ASSEMBLY	5983A10006T	5983A10006T	5983A10006T	-	5983A10006T	R
159901-1	VANE,HORIZONTAL	5990A20008A	5990A20008A	5990A20008A	4995A11004D	5990A20008A	R
159901-2	VANE,HORIZONTAL	5990A20009A	5990A20009A	5990A20009A	5990A20009A	5990A20009A	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A20361E	4995A20361K	4995A20361F	4995A20361F	4995A20361L	R
263230-1	THERMISTOR ASSEMBLY	6323AQ3226T	6323AQ3226T	6323AQ3226T	6323AQ3226T	6323AQ3226T	R
263230-2	THERMISTOR ASSEMBLY	6323A20004A	6323A20004A	6323A20004A	6323A20004A	6323A20004A	R
266090	H.V ASSEMBLY	6609A10003L	6609A10003L	6609A10003L	-	6609A10003L	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20067J	6711A20067H	6711A20067J	6711A20083F	6711A20067H	R
268712	PWB(PCB) ASSEMBLY,DISPLAY	6871A20194B	6871A20194B	6871A20194B	6871A20194B	6871A20194B	R
268715	PWB(PCB) ASSEMBLY,MAIN(AC)	6871A20267B	6871A20267B	6871A20267B	6871A20267B	6871A20267B	R
268716	PWB(PCB) ASSEMBLY,MAIN(DC)	6871A20440E	6871A20440L	6871A20440F	6871A20440F	6871A20440M	R
342800	BEARING	4280A20004A	4280A20004A	4280A20004A	4280A20004A	4280A20004A	R
346810	MOTOR ASSEMBLY,INDOOR	4681A20003D	4681A20003D	4681A20067A	4681A20067A	4681A20067A	R
352111	TUBE ASSEMBLY,CONNECTOR	5211A20514B	5211A20514B	5211A20514B	5211A20514B	5211A20514B	R
352115	TUBE ASSEMBLY,EVAPORATOR IN	5211A30058H	5211A30058H	5211A30097J	5211A30097J	5211A30097J	R
352116	TUBE ASSEMBLY,EVAPORATOR OUT	5211A30057D	5211A30057D	5211A30098G	5211A30098G	5211A30098G	R
352150	HOSE ASSEMBLY,DRAIN	5251AR2575F	5251AR2575F	5251AR2575F	5251AR2575F	5251AR2575F	R
359011	FAN ASSEMBLY,CROSS FLOW	5901A20008A	5901A20008B	5901A20008A	5901A20008A	5901A20008B	R
733010	PLATE ASSEMBLY,INSTALL	3301A10002A	3301A10002A	3301A10002A	3301A10002A	3301A10002A	R
35211B	TUBE ASSEMBLY,TUBING	5211A30439E	5211A30439E	5211A30439J	5211A30439J	5211A30439J	R
W0CZZ	CAPACITOR,DRAWING	3H01487G	3H01487G	3H01487G	3H01487G	3H01487G	R


SP1 Chassis



LOCATION No.	DESCRIPTION	PART No.				SVC CODE
		AMNH096AP*1	AMNC096AP*1	AMNH126AP*1	AMNC126AP*1	
131410	CHASSIS ASSEMBLY	3141A20004N	3141A20004N	3141A20004N	3141A20004N	R
135500-1	COVER	3550A20123A	3550A20123A	3550A20123A	3550A20123A	R
135500-2	COVER	3550A20124A	3550A20124A	3550A20124A	3550A20124A	R
135500-3	COVER	3550A20060A	3550A20060A	3550A20060A	3550A20060A	R
135311-1	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A20069G	3531A20069G	3531A20069G	3531A20069G	R
135311-2	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A20069H	3531A20069H	3531A20069H	3531A20069H	R
135311-3	GRILLE ASSEMBLY,DISCHARGE(INDOOR)	3531A20069J	3531A20069J	3531A20069J	3531A20069J	R
135314	GRILLE ASSEMBLY,INLET	3531A20212K/L/M	3531A20212K/L/M	3531A20212K/L/M	3531A20212K/L/M	R
135515	COVER ASSEMBLY,TOP(INDOOR)	3551A20031B	3551A20031B	3551A20031B	3551A20031B	R
135316	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A20213N/P/Q	3531A20213N/P/Q	3531A20213R/S/T	3531A20213R/S/T	R
147581	LOUVER,HORIZONTAL	4758A20014B	4758A20014B	4758A20014B	4758A20014B	R
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	4681A20055A	4681A20055A	R
152302	FILTER(MECH),A/C	5230A20032A	5230A20032A	5230A20032A	5230A20032A	R
159830	AIR CLEANER ASSEMBLY	5983A20007F	5983A20007F	5983A20007F	5983A20007F	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A20372H	4995A20372N	4995A20372J	4995A20372P	R
249941	CONTROL BOX,INDOOR	4994A10046A	4994A10046A	4994A10046A	4994A10046A	R
268715	PWB(PCB) ASSEMBLY,MAIN(AC)	6871A20380D	6871A20380D	6871A20380D	6871A20380D	R
268716	PWB(PCB) ASSEMBLY,MAIN(DC)	6871A20381D	6871A20381G	6871A20381F	6871A20381H	R
266090	H.V ASSEMBLY	6609A10003S	6609A10003S	6609A10003S	6609A10003S	R
263230-1	THERMISTOR ASSEMBLY	6323AQ6226T	6323AQ6226T	6323AQ6226T	6323AQ6226T	R
263230-2	THERMISTOR ASSEMBLY	6323A20004N	6323A20004N	6323A20004N	6323A20004N	R
268712	PWB(PCB) ASSEMBLY,DISPLAY	6871A20388A	6871A20388B	6871A20388A	6871A20388B	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20073D	6711A20073E	6711A20073E	6711A20073E	R
330870	DRAIN PAN ASSEMBLY	3087A30004A	3087A30004A	3087A30004A	3087A30004A	R
346810	MOTOR ASSEMBLY,INDOOR	4681A20091A	4681A20091A	4681A20091A	4681A20091A	R
349600	MOUNT,MOTOR	4960A20016A	4960A20016A	4960A20016A	4960A20016A	R
352116	TUBE ASSEMBLY,EVAPORATOR OUT	5211A20301J	5211A20301J	5211A20301J	5211A20301J	R
352115	TUBE ASSEMBLY,EVAPORATOR IN	5211A20302J	5211A20302J	5211A20302J	5211A20302J	R
35211B	TUBE ASSY,TUBING	5211AR7066F	5211AR7066F	5211AR7066F	5211AR7066F	R
352150	HOSE ASSEMBLY,DRAIN	5251AR1222R	5251AR1222R	5251AR1222R	5251AR1222R	R
352380	AIR GUIDE	5238A20020A	5238A20020A	5238A20020A	5238A20020A	R
354210	EVAPORATOR ASSEMBLY,FIRST	5421A20072A	5421A20072A	5421A20072A	5421A20072A	R
359012	FAN,TURBO	5900A00003A	5900A00003A	5900A00003A	5900A00003A	R


2. Outdoor Unit

A2UH146FA0/A2UC146FA0




LOCATION No.	DESCRIPTION	PART No.		SVC CODE
		A2UH146FA0	A2UC146FA0	
263230	THERMISTOR ASSEMBLY	6323A20023G		R
430410	BASE ASSY,OUTDOOR	2H02079T	2H02079T	R
435301	GRILLE,DISCHARGE	1H00840C	1H00840C	R
437211	PANEL ASSEMBLY,FRONT(OUTDOOR)	2H02674S	2H02674S	R
435512	COVER ASSY, TOP(OUTDOOR)	3H03465D	3H03465D	R
437212	PANEL ASSY,REAR	1H00697N	1H00697N	R
447910	BARRIER ASSY,OUTDOOR	3H03466F	3H03466F	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681AR1392Q	1H00853D	R
550140	ISOLATOR,COMP	4H00982E	4H00982E	R
552111-1	TUBE ASSEMBLY,CAPILLARY	5211A10381C		R
552111-2	TUBE ASSEMBLY,CAPILLARY		5211A10381A	R
552115	TUBE ASSEMBLY,MENIFOLD(OUTDOOR)	5211A20952C		R
552116	TUBE ASSEMBLY,REVERSING	5211A10053C		R
552117	TUBE ASSEMBLY,SUCTION(OUTDOOR)		5211A20935A	R
552203-1	VALVE,SERVICE	2H02479H	2H02479H	R
552203-2	VALVE,SERVICE	5220A20001J	5220A20001J	R
559010	FAN ASSEMBLY,PROPELLER	5900AR1119B	5900AR1119B	R
554031	CONDENSER ASSEMBLY,BENT	5403A20134C	5403A20134D	R
554160	COMPRESSOR SET	2520UTGP2AA	2520UTGP2AA	R
561410-1	COIL ASSEMBLY,SOLENOID	6141A20013F	6141A20013F	R
561410-2	COIL ASSEMBLY,REVERSING VALVE	6141A20010B		R
561410-3	COIL ASSEMBLY,SOLENOID	6141A20013D	6141A20013D	R
561410-4	COIL ASSEMBLY,REVERSING VALVE	6141A20013G	6141A20013G	R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A20112H	4995A20112J	R
668711	PWB(PCB) ASSEMBLY,MAIN(OUTDOOR)	6871A20414H	6871A20414J	R
W0CZZ	CAPACITOR,DRAWING	2H01451S	2H01451T	R
552114	TUBE ASSEMBLY, DISCHARGE		5211A20951A	R

A2UH186FA0




A2UC186FA0




Exploded View & Replacement Parts List

LOCATION No.	DESCRIPTION	PART No.		SVC CODE
		A2UH186FA0	A2UC186FA0	
435300	GRILLE,REAR	1A00207B		R
137213-1	PANEL ASSEMBLY,SIDE	1A00201D		R
137213-2	PANEL ASSY,SIDE	3A02284M		R
263230	THERMISTOR ASSEMBLY	6323A20023A	6323A20023B	R
430410	BASE ASSEMBLY,OUTDOOR	3041AP2741H	3041AP2741H	R
435511	COVER ASSEMBLY,CONTROL(OUTDOOR)	3551A20076H	3551A20076K	R
437212	PANEL ASSY,REAR		3720AP0003F	R
435301	GRILL, DISCHARGE	3530A20007B	3530A20007B	R
435512	COVER ASSEMBLY,TOP(OUTDOOR)	3551A30113B	3H03266K	R
437211	PANEL ASSEMBLY, FRONT(OUTDOOR)	3721A23001A	3721A20005P	R
447910	BARRIER ASSEMBLY,OUTDOOR	4791A30004K	4791A30004K	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681A20028J	4681A20028J	R
548490	ACCUMULATOR ASSEMBLY(MECH)	4849A20039B	4849A20042A	R
550140	ISOLATOR,COMP	4H00982E	4H00982E	R
552203-1	VALVE,SERVICE	5220A20001K	5220A20001K	R
552203-2	VALVE,SERVICE	2H02479R	2H02479R	R
554160-1	COMPRESSOR	5416A90022C	5416A90022C	R
554160-2	COMPRESSOR	5416A90022A	5416A90022A	R
561411-1	COIL ASSEMBLY,EXPANSION	6141A20018A	6141A20018A	R
561411-2	COIL ASSEMBLY,EXPANSION	6141A20018B	6141A20018B	R
552112	TUBE ASSEMBLY,CONDENSER IN	5211A01001B	5211A10458A	R
552113	TUBE ASSEMBLY,CONDENSER OUT	5211A00001A	5211A00001B	R
552114	TUBE ASSEMBLY,DISCHARGE		5211A10456A	R
552116	TUBE ASSEMBLY,REVERSING	5211A10445C		R
554031	CONDENSER ASSEMBLY,BENT	5403A20072N	5403A20072R	R
559010	FAN ASSEMBLY,PROPELLER	5901A10032A	5901A10032A	R
561410	COIL ASSEMBLY,REVERSING VALVE	6141A20010J		R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A10112A	4995A10112B	R
268711	PWB(PCB) ASSEMBLY,MAIN(OUTDOOR)	6871A20414B	6871A20414C	R
W0CZZ-1	CAPACITOR,DRAWING	6120AR2194D	6120AR2194D	R
W0CZZ-2	CAPACITOR,DRAWING	2A00986G	2A00986G	R

A3UC216FA0




A3UH216FA0




LOCATION No.	DESCRIPTION	PART No.		SVC CODE
		A3UH216FA0	A3UC216FA0	
135314	GRILLE,REAR	1A00207B		R
137213-1	PANEL ASSEMBLY,SIDE	1A00201D		R
137213-2	PANEL ASSY,SIDE	3A02284M		R
263230	THERMISTOR ASSEMBLY	6323A20023A	6323A20023B	R
430410	BASE ASSEMBLY,OUTDOOR	3041AP2741H	3041AP2741H	R
435301	GRILL, DISCHARGE	3530A20007B		R
435511	COVER ASSEMBLY,CONTROL(OUTDOOR)	3551A30088D	3551A30061G	R
435512	COVER ASSEMBLY,TOP(OUTDOOR)	3551A30113B	3H03266K	R
437211	PANEL ASSEMBLY, FRONT(OUTDOOR)	3721A23001A	3721A20005P	R
437212	PANEL ASSY,REAR		3720AP0003F	R
447910	BARRIER ASSEMBLY,OUTDOOR	4791A30004K	4791A30004K	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681A20028J	4681A20028J	R
548490	ACCUMULATOR ASSEMBLY(MECH)	4849A20039A	4849A20042A	R
550140	ISOLATOR,COMP	4H00982E	4H00982E	R
552112	TUBE ASSEMBLY,CONDENSER IN	5211A01001B	5211A10458A	R
552113	TUBE ASSEMBLY,CONDENSER OUT	5211A00001A	5211A00001B	R
552114	TUBE ASSEMBLY,DISCHARGE (OUTDOOR)		5211A10456B	R
552116	TUBE ASSEMBLY,REVERSING	5211A10445B		R
552203-1	VALVE,SERVICE	5220A20001K	5220A20001K	R
552203-2	VALVE,SERVICE	2H02479R	2H02479R	R
554160-1	COMPRESSOR	5416A90022D	5416A90022D	R
554160-2	COMPRESSOR	5416A90022B	5416A90022B	R
561411-1	COIL ASSEMBLY,EXPANSION	6141A20018A	6141A20018A	R
561411-2	COIL ASSEMBLY,EXPANSION	6141A20018B	6141A20018B	R
561411-3	COIL ASSEMBLY,EXPANSION	6141A20018C	6141A20018C	R
554031	CONDENSER ASSEMBLY,BENT	5403A20072N	5403A20072R	R
559010	FAN ASSEMBLY,PROPELLER	5901A10032A	5901A10032A	R
561410	COIL ASSEMBLY,REVERSING VALVE	6141A20010J		R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A10112C	4995A10112D	R
668711	PWB(PCB) ASSEMBLY,MAIN(OUTDOOR)	6871A20414D	6871A20414E	R
W0CZZ-1	CAPACITOR,DRAWING	6120AR2194D	6120AR2194D	R
W0CZZ-2	CAPACITOR,DRAWING	2H00841Z	2H00841Z	R

A4UH306FA0



A4UC306FA0



LOCATION No.	DESCRIPTION	PART No.		SVC CODE
		A4UH306FA0	A4UC306FA0	
135301	GRILLE,DISCHARGE	3530A20006G	3530A20006G	R
135314	GRILLE,REAR	3530A10176B	3530A10176B	R
263230	THERMISTOR ASSEMBLY	6323A20023E	6323A20023F	R
430410	BASE ASSY, OUTDOOR	3041AP7177D	3041AP7177D	R
435511	COVER ASSEMBLY,CONTROL(OUTDOOR)	3551A30088F	3551A30088G	R
435512	COVER ASSEMBLY,TOP(OUTDOOR)	3H03266H	3H03266H	R
437211	PANEL ASSEMBLY,FRONT(OUTDOOR)	3721A10109A	3721A10109A	R
447910	BARRIER ASSEMBLY,OUTDOOR	4791A10019B	4791A10019B	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681AR1392Y	4681AR1392Y	R
552114	TUBE ASSEMBLY,DISCHARGE (OUTDOOR)		5211A11013A	R
548490	ACCUMULATOR ASSEMBLY(MECH)	4849A10039A	4849A10039B	R
550140	ISOLATOR,COMP	4H00982E	4H00982E	R
552112	TUBE ASSEMBLY,CONDENSER IN	5211A11010A	5211A11010A	R
552113	TUBE ASSEMBLY,CONDENSER OUT	5211A12001A	5211A12001B	R
552116	TUBE ASSEMBLY,REVERSING	5211A10453A		R
552117	TUBE ASSEMBLY,SUCTION(OUTDOOR)	5211A11012A	5211A11012A	R
554031	CONDENSER ASSEMBLY,BENT	5403A20168B	5403A20168B	R
559010	FAN ASSEMBLY,PROPELLER	5901A10033A	5901A10033A	R
561410	COIL ASSEMBLY,REVERSING VALVE	6141A20010K		R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A10117A	4995A10117B	R
668711	PWB(PCB) ASSEMBLY,MAIN(OUTDOOR)	6871A20414F	6871A20414G	R
137213-1	PANEL ASSEMBLY,SIDE	3721A10110A	3721A10110A	R
137213-2	PANEL ASSEMBLY,SIDE	3721A10111A	3721A10111A	R
552203-1	VALVE,SERVICE	5220A20001K	5220A20001K	R
552203-2	VALVE,SERVICE	2H02479R	2H02479R	R
554160-1	COMPRESSOR	5416A90022E	5416A90022E	R
554160-2	COMPRESSOR	5416A90022D	5416A90022D	R
561411-1	COIL ASSEMBLY,EXPANSION	6141A20018D	6141A20018D	R
561411-2	COIL ASSEMBLY,EXPANSION	6141A20018E	6141A20018E	R
561411-3	COIL ASSEMBLY,EXPANSION	6141A20018F	6141A20018F	R
561411-4	COIL ASSEMBLY,EXPANSION	6141A20018G	6141A20018G	R
W0CZZ-1	CAPACITOR,DRAWING	0CZZA20007R	0CZZA20007R	R
W0CZZ-2	CAPACITOR,DRAWING	2H01451V	2H01451V	R