



Exploded View and Replacement Parts List

1. Indoor Unit

Ceiling Cassette Type

ATNC-EL, ATNH-EL







Parts List

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		ATNC186ELAA	ATNC186ELCA	ATNH186ELAA	ATNH186ELCA	
130411	BASE ASSY,WELD(INDOOR)	3041A10013A	3041A10013A	3041A10013A	3041A10013A	R
130911-1	CABINET ASSEMBLY,INDOOR	3091A10023C	3091A10023C	3091A10023C	3091A10023C	R
130911-2	CABINET ASSEMBLY,INDOOR	3091A10023D	3091A10023D	3091A10023D	3091A10023D	R
158591	PUMP ASSEMBLY,WATER	5859A20001M	5859A20001M	5859A20001M	5859A20001M	R
159830	AIR CLEANER ASSEMBLY	-	5983A10002A	-	5983A10002A	R
249941	CONTROL BOX ASSEMBLY,INDOOR	4994A10014A	4995A20168B	4994A10014A	4995A20168B	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A14001B	4995A14001B	4995A14001A	4995A14001A	R
263230-1	THERMISTOR ASSEMBLY	6323A10002A	6323A10002A	6323A10002A	6323A10002A	R
263230-2	THERMISTOR ASSEMBLY	6323AQ3226F	6323AQ3226F	6323AQ3226F	6323AQ3226F	R
266012	SWITCH ASSY,FLOAT	6601A20001G	6601A20001G	6601A20001G	6601A20001G	R
266090	H.V ASSY	-	6609A20005C	-	6609A20005C	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20039G	6711A20039J	6711A20039H	6711A20039K	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20076A	6711A20076K	6711A20076A	6711A20076J	R
330870	DRAIN PAN ASSEMBLY	3087A10002A	3087A10002A	3087A10002A	3087A10002A	R
346810	MOTOR ASSY,SINGLE	4681AC2026D	4681AC2026D	4681AC2026D	4681AC2026D	R
35211A	TUBE ASSEMBLY,SUCTION INDOOR	5211A20243L	5211A20243L	5211A20243L	5211A20243L	R
354211	EVAPORATOR ASSEMBLY,BENDING	5421A10006E	5421A10006E	5421A10006E	5421A10006E	R
359011	FAN,TURBO	5900A10004A	5900A10004A	5900A10004A	5900A10004A	R
552118	TUBE ASSEMBLY,MENIFOLD(INDOOR)	5211A20241F	5211A20241F	5211A20241F	5211A20241F	R
W0CZZ	CAPACITOR,DRAWING	3H00660N	3H00660N	3H00660N	3H00660N	R
268714	PWB(PCB) ASSEMBLY MAIN	6871A10105J	6871A10105J	6871A10105H	6871A10105H	R

Ceiling Cassette Type

ATNC-FL, ATNH-FL





Parts List


LOCATION No.	DESCRIPTION	Part No.				REMARKS
		ATNC246FLAA	ATNC246FLCA	ATNH246FLAA	ATNH246FLCA	
130411	BASE ASSEMBLY,WELD[INDOOR]	3041A10030B	3041A10030B	3041A10030B	3041A10030B	R
130911	CABINET ASSEMBLY,INDOOR	3091A10051A	3091A10051A	3091A10051A	3091A10051A	R
130911	CABINET ASSEMBLY,INDOOR	3091A10051B	3091A10051B	3091A10051B	3091A10051B	R
158591	PUMP ASSEMBLY,WATER	5859A20001K	5859A20001K	5859A20001K	5859A20001K	R
159830	AIR CLEANER ASSEMBLY	-	5983A10002A	-	5983A10002A	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A10093F	4995A10093F	4995A10093C	4995A10093C	R
263230-1	THERMISTOR ASSEMBLY	6323AQ3226E	6323AQ3226E	6323AQ3226E	6323AQ3226E	R
263230-2	THERMISTOR ASSEMBLY	6323AQ3226E	6323AQ3226E	6323AQ3226E	6323AQ3226E	R
266012	SWITCH ASSEMBLY,FLOAT	6601A20001H	6601A20001H	6601A20001H	6601A20001H	R
266090	H.V ASSEMBLY	-	6609A20005E	-	6609A20005E	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20039G	6711A20039J	6711A20039H	-	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20076A	6711A20076K	6711A20076A	-	R
268714	PWB(PCB) ASSEMBLY,MAIN	6871A10105G	6871A10105G	6871A10105F	6871A10105F	R
330870	DRAIN PAN ASSEMBLY	3087A10010B	3087A10010B	3087A10010B	3087A10010B	R
346810	MOTOR ASSEMBLY,INDOOR	4681A20051Z	4681A20051Z	4681A20051Z	4681A20051Z	R
349490	ORIFICE ASSEMBLY	4949A10007A	4949A10007B	4949A10007A	-	R
352118	TUBE ASSEMBLY,MENIFOLD(INDOOR)	5211A20251K	5211A20251K	5211A20251K	5211A20251K	R
352118	TUBE ASSEMBLY,MENIFOLD(INDOOR)	5211A20251L	5211A20251L	5211A20251L	5211A20251L	R
354211	EVAPORATOR ASSEMBLY,BENDING	5421A10016G	5421A10016G	5421A10016G	5421A10016G	R
354211	EVAPORATOR ASSEMBLY,BENDING	5421A10016H	5421A10016H	5421A10016H	5421A10016H	R
359012	FAN ASSEMBLY,TURBO	5901A10036A	5901A10036A	5901A10036A	5901A10036A	R
552111	TUBE ASSEMBLY,CAPILLARY	5211A21137A	5211A21137A	5211A21137A	5211A21137A	R
W0CZZ	CAPACITOR,DRAWING	3H00660M	3H00660M	3H00660M	3H00660M	R


Parts List

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		ATNC306FLAA	ATNC306FLCA	ATNH306FLAA	ATNH306FLCA	
130411	BASE ASSEMBLY,WELD[INDOOR]	3041A10030B	3041A10030B	3041A10030B	3041A10030B	R
130911	CABINET ASSEMBLY,INDOOR	3091A10051A	3091A10051A	3091A10051A	3091A10051A	R
130911	CABINET ASSEMBLY,INDOOR	3091A10051B	3091A10051B	3091A10051B	3091A10051B	R
158591	PUMP ASSEMBLY,WATER	5859A20001K	5859A20001K	5859A20001K	5859A20001K	R
266012	SWITCH ASSEMBLY,FLOAT	6601A20001H	6601A20001H	6601A20001H	6601A20001H	R
159830	AIR CLEANER ASSEMBLY	-	5983A10002A	-	5983A10002A	R
266090	H.V ASSEMBLY	-	6609A20005E	-	6609A20005E	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A10093J	4995A10093J	4995A10093G	4995A10093G	R
249951	CONTROL BOX,INDOOR	4994A10041A	4994A10041A	4994A10041A	4994A10041A	R
263230-1	THERMISTOR ASSEMBLY	6323AQ3226E	6323AQ3226E	6323AQ3226E	6323AQ3226E	R
263230-2	THERMISTOR ASSEMBLY	6323A10002A	6323A10002A	6323A10002A	6323A10002A	R
267110	REMOTE CONTROLLER ASSEMBLY	-	6711A20039J	-	6711A20039K	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20076B	6711A20076K	6711A20076A	6711A20076J	R
330870	DRAIN PAN ASSEMBLY	3087A10010B	3087A10010B	3087A10010B	3087A10010B	R
346810	MOTOR ASSEMBLY,INDOOR	4681A20051W	4681A20051W	4681A20051W	4681A20051W	R
349490	ORIFICE ASSEMBLY	4949A10007A	4949A10007B	4949A10007A	4949A10007B	R
354211	EVAPORATOR ASSEMBLY,BENDING	5421A10016G	5421A10016G	5421A10016G	5421A10016G	R
354211	EVAPORATOR ASSEMBLY,BENDING	5421A10016H	5421A10016H	5421A10016H	5421A10016H	R
552111	TUBE ASSEMBLY,CAPILLARY	5211A21137A	5211A21137A	5211A21137A	5211A21137A	R
352118	TUBE ASSEMBLY,MENIFOLD(INDOOR)	5211A20251K	5211A20251K	5211A20251K	5211A20251K	R
352118	TUBE ASSEMBLY,MENIFOLD(INDOOR)	5211A20251L	5211A20251L	5211A20251L	5211A20251L	R
359012	FAN ASSEMBLY,TURBO	5901A10036A	5901A10036A	5901A10036A	5901A10036A	R
W0CZZ	CAPACITOR,DRAWING	3H00660M	3H00660M	3H00660M	3H00660M	R
268714	PWB(PCB) ASSEMBLY MAIN	6871A10105L	6871A10105L	6871A10105K	6871A10105K	R

Ceiling Cassette Type

ATNC-DL, ATNH-DL





Parts List


LOCATION No.	DESCRIPTION	Part No.			REMARKS
		ATNC368DLCA	ATNH368DLCA	ATNC488DLCA	
130411	BASE ASSEMBLY,WELD[INDOOR]	3041A10016A	3041A10016A	3041A10016A	R
130911-1	CABINET ASSEMBLY,INDOOR	3091A10030A	3091A10030A	3091A10030A	R
130911-2	CABINET ASSEMBLY,INDOOR	3091A10030B	3091A10030B	3091A10030B	R
130911-3	CABINET ASSEMBLY,INDOOR	3091A10031A	3091A10031A	3091A10031A	R
130911-4	CABINET ASSEMBLY,INDOOR	3091A10031B	3091A10031B	3091A10031B	R
158591	PUMP ASSEMBLY,WATER	5859A20001D	5859A20001D	5859A20001D	R
266012	SWITCH ASSEMBLY,FLOAT	6601A20001F	6601A20001F	6601A20001F	R
159830	AIR CLEANER ASSEMBLY	5983A10003D	5983A10003D	5983A10003D	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A20168A	4995A20168A	4995A20168A	R
349490	CONTROL BOX ASSY	4995A22004B	4995A22004A	4995A22004D	R
263230-1	THERMISTOR ASSEMBLY	6323AQ3226F	6323AQ3226F	6323AQ3226F	R
263230-2	THERMISTOR ASSEMBLY	6323A10002B	6323A10002B	6323A10002B	R
266090	H.V ASSEMBLY	6609A20005D	6609A20005D	6609A20005D	R
267110-1	REMOTE CONTROLLER ASSEMBLY	6711A20039J	-	-	R
267110-2	REMOTE CONTROLLER ASSEMBLY	6711A20076K	-	-	R
330870	DRAIN PAN ASSEMBLY	3087A10006A	3087A10006A	3087A10006A	R
346810	MOTOR ASSEMBLY,INDOOR	4681A20006J	4681A20006J	4681A20006H	R
354211-1	EVAPORATOR ASSEMBLY,BENDING	5421A10016B	5421A10016B	5421A10016B	R
354211-2	EVAPORATOR ASSEMBLY,BENDING	5421A10016A	5421A10016A	5421A10016A	R
552111	TUBE ASSEMBLY,CAPILLARY	5211A20316E	5211A20316E	5211A20316A	R
352118-1	TUBE ASSEMBLY,MENIFOLD(INDOOR)	5211A20251C	5211A20251C	5211A20251A	R
352118-2	TUBE ASSEMBLY,MENIFOLD(INDOOR)	5211A20251B	5211A20251B	5211A20251B	R
359012	FAN ASSEMBLY,TURBO	5900A10003B	5900A10003B	5900A10003B	R
W0CZZ	CAPACITOR,DRAWING	3H00660M	3H00660M	2A00986D	R
268714	PWB(PCB) ASSEMBLY MAIN	6871A10105S	6871A10105R	6871A10105N	R

Parts List

LOCATION No.	DESCRIPTION	Part No.			REMARKS
		ATNH488DLCA	ATNC608DLCA	ATNH608DLCA	
130411	BASE ASSEMBLY,WELD[INDOOR]	3041A10016A	3041A10016A	3041A10016A	R
130911-1	CABINET ASSEMBLY,INDOOR	3091A10030A	3091A10030A	3091A10030A	R
130911-2	CABINET ASSEMBLY,INDOOR	3091A10030B	3091A10030B	3091A10030B	R
130911-3	CABINET ASSEMBLY,INDOOR	3091A10031A	3091A10031A	3091A10031A	R
130911-4	CABINET ASSEMBLY,INDOOR	3091A10031B	3091A10031B	3091A10031B	R
158591	PUMP ASSEMBLY,WATER	5859A20001D	5859A20001D	5859A20001D	R
266012	SWITCH ASSEMBLY,FLOAT	6601A20001F	6601A20001F	6601A20001F	R
159830	AIR CLEANER ASSEMBLY	5983A10003D	5983A10003D	5983A10003D	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A20168A	4995A20168A	4995A20168A	R
349490	CONTROL BOX ASSY	4995A22004C	4995A22004F	4995A22004E	R
263230-1	THERMISTOR ASSEMBLY	6323AQ3226F	6323AQ3226F	6323AQ3226F	R
263230-2	THERMISTOR ASSEMBLY	6323A10002B	6323A10002B	6323A10002B	R
266090	H.V ASSEMBLY	6609A20005D	6609A20005D	6609A20005D	R
267110-1	REMOTE CONTROLLER ASSEMBLY	6711A20039K	-	6711A20039K	R
267110-2	REMOTE CONTROLLER ASSEMBLY	6711A20076J	-	6711A20076J	R
330870	DRAIN PAN ASSEMBLY	3087A10006A	3087A10006A	3087A10006A	R
346810	MOTOR ASSEMBLY,INDOOR	4681A20006H	4681A20006M	4681A20006M	R
354211-1	EVAPORATOR ASSEMBLY,BENDING	5421A10016B	5421A10016B	5421A10016B	R
354211-2	EVAPORATOR ASSEMBLY,BENDING	5421A10016A	5421A10016A	5421A10016A	R
552111	TUBE ASSEMBLY,CAPILLARY	5211A20316A	5211A20316B	5211A20316B	R
352118-1	TUBE ASSEMBLY,MENIFOLD(INDOOR)	5211A20251A	5211A20251A	5211A20251A	R
352118-2	TUBE ASSEMBLY,MENIFOLD(INDOOR)	5211A20251B	5211A20251B	5211A20251B	R
359012	FAN ASSEMBLY,TURBO	5900A10003B	5900A10003B	5900A10003B	R
W0CZZ	CAPACITOR,DRAWING	2A00986D	2A00986D	2A00986D	R
268714	PWB(PCB) ASSEMBLY MAIN	6871A10105M	6871A10105Q	6871A10105P	R

Ceiling Concealed Duct Type

**ATNC-HL, ABNC-GL,
ATNH-HL, ABNH-GL**



Parts List


LOCATION No.	DESCRIPTION	Part No.				REMARKS
		ABNC186HLAA	ABNH186HLAA	ABNC246HLAA	ABNH246HLAA	
336610-1	HOUSING (MECH)	3660A20017A	3660A20017A	3660A20017A	3660A20017A	R
336610-2	HOUSING (MECH)	3660A20018A	3660A20018A	3660A20018A	3660A20018A	R
346810	MOTOR ASSEMBLY,INDOOR	4681A10013C	4681A10013C	4681A10013C	4681A10013C	R
359012-1	FAN ASSEMBLY,BLOWER	5901A10028B	5901A10028B	5901A10028B	5901A10028B	R
359012-2	FAN ASSEMBLY,BLOWER	5901A10026A	5901A10026A	5901A10026A	5901A10026A	R
W0CZZ	CAPACITOR,DRAWING	2A00986D	2A00986D	2A00986D	2A00986D	R
354210	EVAPORATOR ASSEMBLY	5421A20100A	5421A20100A	5421A20100B	5421A20100B	R
352118	TUBE ASSEMBLY,MENIFOLD	5211A20465B	5211A20465B	5211A20465B	5211A20465B	R
552111	TUBE ASSEMBLY,CAPI	5211A20466J	5211A20466J	5211A20466H	5211A20466H	R
33860	DRAIN PAN ASSEMBLY	3087A10008B	3087A10008B	3087A10008B	3087A10008B	R
249951	CONTROL BOX ASSEMBLY	4995A10081A	4995A20164N	4995A10081B	4995A20164Q	R
268714	PWB(PCB) ASSEMBLY	6871A10071P	6871A10071G	6871A10071Q	6871A10071H	R
263230-1	THERMISTOR ASSY	6323AQ3226G	6323AQ3226G	6323AQ3226G	6323AQ3226G	R
263230-2	THERMISTOR ASSEMBL	6323AQ3214E	6323AQ3214E	6323AQ3214E	6323AQ3214E	R
267110-1	REMOTE CONTROLLER	6711A20043E	6711A20043D	6711A20043E	6711A20043D	R
267110-2	REMOTE CONTROLLER	6711A20041D	6711A20041E	6711A20041D	6711A20041E	R
152302	FILTER(MECH),A/C	5230A30001M	5230A30001M	5230A30001M	5230A30001M	R

Parts List

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		ABNC306GLAA	ABNH306GLAA	ABNC368GLAA	ABNH368GLAA	
336610-1	HOUSING (MECH),WRAPPER	3660A20019A	3660A20019A	3660A20019A	3660A20019A	R
336610-2	HOUSING (MECH),WRAPPER	3660A20020A	3660A20020A	3660A20020A	3660A20020A	R
346810	MOTOR ASSEMBLY,INDOOR	4681A10013J	4681A10013J	4681A10013A	4681A10013A	R
359012-1	FAN ASSEMBLY,BLOWER	5901A10026A	5901A10026A	5901A10026A	5901A10026A	R
359012-2	FAN ASSEMBLY,BLOWER	5901A10028J	5901A10028J	5901A10028A	5901A10028A	R
W0CZZ	CAPACITOR,DRAWING	2A00986D	2A00986D	2A00986D	2A00986D	R
354210	EVAPORATOR ASSEMBLY,FIRST	5421A10027A	5421A10027A	5421A10027A	5421A10027A	R
552111	TUBE ASSEMBLY,CAPILLARY	5211A20450G	5211A20450G	5211A20450H	5211A20450H	R
352118	TUBE ASSEMBLY,MENIFOLD(INDOOR)	5211A20416A	5211A20416A	5211A20416A	5211A20416A	R
330860	DRAIN PAN ASSEMBLY	3087A10008A	3087A10008A	3087A10008A	3087A10008A	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A22003B	4995A22003A	4995A20164B	4995A20011W	R
268714	PWB(PCB) ASSEMBLY,MAIN	6871A20181J	6871A20181H	6871A20181B	6871A20181A	R
263230-1	THERMISTOR ASSY	6323AQ3226G	6323AQ3226G	6323AQ3226G	6323AQ3226G	R
263230-2	THERMISTOR ASSEMBLY	6323AQ3214E	6323AQ3214E	6323AQ3214E	6323AQ3214E	R
267110-1	REMOTE CONTROLLER ASSEMBLY	6711A20043E	6711A20043D	6711A20043E	6711A20043D	R
267110-2	REMOTE CONTROLLER ASSEMBLY	6711A20041D	6711A20041E	6711A20041D	6711A20041E	R
152302	FILTER(MECH),A/C	5230A30001L	5230A30001L	5230A30001L	5230A30001L	R

Ceiling Concealed Duct Type

ABNC-EL, ABNH-EL




Parts List

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		ABNC488ELAA	ABNH488ELAA	ABNC608ELAA	ABNH608ELAA	
336610-1	HOUSING (MECH),WRAPPER	3661A10009E	3661A10009E	3661A10009E	3661A10009E	R
336610-2	HOUSING (MECH),WRAPPER	3661A10009F	3661A10009F	3661A10009F	3661A10009F	R
346810	MOTOR ASSEMBLY,INDOOR	4681A20005K	4681A20005K	4681A20005Q	4681A20005Q	R
359012-1	FAN ASSEMBLY,BLOWER	5901A10015E	5901A10015E	5901A10015E	5901A10015E	R
359012-2	FAN ASSEMBLY,BLOWER	5901A10015F	5901A10015F	5901A10015F	5901A10015F	R
W0CZZ	CAPACITOR,DRAWING	0CZZA20001C	0CZZA20001C	0CZZA20001B	0CZZA20001B	R
354210	EVAPORATOR ASSEMBLY,FIRST	5421A20008A	5421A20008A	5421A20008E	5421A20008E	R
35211C-1	TUBE ASSY,DISCHARGE (INDOOR)	5211A30077A	5211A30077A	5211A30077A	5211A30077A	R
35211C-2	TUBE ASSY,DISCHARGE (INDOOR)	5211A30094B	5211A30094B	5211A30077B	5211A30077B	R
330860	DRAIN PAN ASSEMBLY	3086A30001H	3086A30001H	3086A30001H	3086A30001H	R
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A20164K	4995A20164J	4995A20164K	4995A20164J	R
268714	PWB(PCB) ASSEMBLY,MAIN	6871A10010N	6871A10040M	6871A10040N	6871A10010M	R
263230-1	THERMISTOR ASSY	6323AQ3226G	6323AQ3226G	6323AQ3226G	6323AQ3226G	R
263230-2	THERMISTOR ASSEMBLY	6323AQ3214Q	6323AQ3214Q	6323AQ3214Q	6323AQ3214Q	R
267110-1	REMOTE CONTROLLER ASSEMBLY	6711A20043E	6711A20043D	6711A20043E	6711A20043D	R
267110-2	REMOTE CONTROLLER ASSEMBLY	6711A20041D	6711A20041E	6711A20041D	6711A20041E	R
152302	FILTER(MECH),A/C	5230A30001A	5230A30001A	5230A30001A	5230A30001A	R

Ceiling & Floor Type

AVNC-BL, AVNH-BL




Parts List

LOCATION No.	DESCRIPTION	Part No.			REMARKS
		AVNC186BLAA	AVNH186BLAA	AVNC246BLAA	
135314	GRILLE ASSEMBLY,INLET SUB	5237AP2817B	5237AP2817B	5237AP2817B	R
137213	PANEL ASSEMBLY,FRONT(INDOOR)	3720AP2767P	3720AP2767P	3720AP2767P	R
146811	MOTOR ASSEMBLY,STEP	4681AR2727G	4681AR2727G	4681AR2727G	R
152302	FILTER(MECH),A/C	5230AP7093A	5230AP7093A	5230AP7093A	R
159911-1	VANE ASSY,HORIZONTAL	5991AP2867B	5991AP2867B	5991AP2867B	R
159911-2	VANE ASSY	5991AP7334C	5991AP7334C	5991AP7334C	R
166000-1	SWITCH,PUSH	6600AP2059B	6600AP2059B	6600AP2059B	R
166000-2	SWITCH,PUSH	6600AP2059B	6600AP2059B	6600AP2059B	R
235450	DISPLAY ASSY (MECH)	3545AP7224A	3545AP7224A	3545AP7224A	R
237900	WINDOW,DISPLAY	3790AP7080A	3790AP7080A	3790AP7080A	R
261704	TRANSFORMER,POWER	6171AQ3198E	6171AQ3198E	6171AQ3198E	R
263230	THERMISTOR ASSEMBLY	6323AQ2333Y	6323AQ2333Y	6323AQ2333Y	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20010J	6711A20010K	6711A20010J	R
268712	PWB(PCB) ASSY,DISPLAY	6871AQ3263A	6871AQ3263A	6871AQ3263A	R
268714	PWB(PCB) ASSY,MAIN	6871A20042L	6871A20042H	6871A20042L	R
330870	DRAIN PAN ASSEMBLY	3087AP7233A	3087AP7233A	3087AP7233A	R
342800	BEARING	3H02821B	3H02821B	3H02821B	R
346810	MOTOR ASSEMBLY,INDOOR	4681AP2306G	4681AP2306G	4681AP2306E	R
352115	TUBE ASSEMBLY,EVAPORATOR IN	5211A20253C	5211A20253C	5211A20253B	R
35211A	TUBE ASSEMBLY,SUCTION INDOOR	5211AP2813D	5211AP2813D	5211AP2813A	R
354210	EVAPORATOR ASSEMBLY,FIRST	5421AP2812B	5421AP2812B	5421AP2812A	R
359010	FAN ASSY,CROSS FLOW	5901AR2351E	5901AR2351E	5901AR2351E	R
352150	HOSE ASSY, DRAIN	5251AP2460B	5251AP2460B	5251AP2460B	R
W0CZZ	CAPACITOR,DRAWING	3H00671A	3H00671A	3H00671A	R
130911	CABINET ASSY(INDOOR)	3091AP2533A	3091AP2533A	3091A2533A	R
249951	CONTROL BOX ASSY, INDOOR	4995A22002B	4995A22002A	4995A22002B	R


Parts List

LOCATION No.	DESCRIPTION	Part No.			REMARKS
		AVNH246BLAA	AVNC306BLAA	AVNH306BLAA	
135314	GRILLE ASSEMBLY,INLET SUB	5237AP2817B	5237AP2817B	5237AP2817B	R
137213	PANEL ASSEMBLY,FRONT(INDOOR)	3720AP2767P	3720AP2767P	3720AP2767P	R
146811	MOTOR ASSEMBLY,STEP	4681AR2727G	4681AR2727G	4681AR2727G	R
152302	FILTER(MECH),A/C	5230AP7093A	5230AP7093A	5230AP7093A	R
159911-1	VANE ASSY,HORIZONTAL	5991AP2867B	5991AP2867B	5991AP2867B	R
159911-2	VANE ASSY	5991AP7334C	5991AP7334C	5991AP7334C	R
166000-1	SWITCH,PUSH	6600AP2059B	6600AP2059B	6600AP2059B	R
166000-2	SWITCH,PUSH	6600AP2059B	6600AP2059B	6600AP2059B	R
235450	DISPLAY ASSY (MECH)	3545AP7224A	3545AP7224A	3545AP7224A	R
237900	WINDOW,DISPLAY	3790AP7080A	3790AP7080A	3790AP7080A	R
261704	TRANSFORMER,POWER	6171AQ3198E	6171AQ3198E	6171AQ3198E	R
263230	THERMISTOR ASSEMBLY	6323AQ2333Y	6323AQ2333Y	6323AQ2333Y	R
267110	REMOTE CONTROLLER ASSEMBLY	6711A20010K	6711A20010J	6711A20010K	R
268712	PWB(PCB) ASSY,DISPLAY	6871AQ3263A	6871AQ3263A	6871AQ3263A	R
268714	PWB(PCB) ASSY,MAIN	6871A20042H	6871A20042L	6871A20042H	R
330870	DRAIN PAN ASSEMBLY	3087AP7233A	3087AP7233A	3087AP7233A	R
342800	BEARING	3H02821B	3H02821B	3H02821B	R
346810	MOTOR ASSEMBLY, INDOOR	4681AP2306E	4681AP2306L	4681AP2306L	R
352115	TUBE ASSEMBLY, EVAPORATOR IN	5211A20253B	5211A20253B	5211A20253B	R
35211A	TUBE ASSEMBLY, SUCTION INDOOR	5211AP2813A	5211AP2813A	5211AP2813A	R
354210	EVAPORATOR ASSEMBLY, FIRST	5421AP2812A	5421AP2812A	5421AP2812A	R
359010	FAN ASSY, CROSS FLOW	5901AR2351E	5901AR2351E	5901AR2351E	R
352150	HOSE ASSY, DRAIN	5251AP2460B	5251AP2460B	5251AP2460B	R
W0CZZ	CAPACITOR, DRAWING	3H00671A	3H00671A	3H00671A	R
130911	CABINET ASSY(INDOOR ASSY)	3019AP2533A	3019AP2533A	3019AP2533A	R
249951	CONTROL BOX ASSY, INDOOR	4995A22002B	4995A22002A	4995A22002B	R

Model No.: AUUC186A/AB




Model No.: AUUH186A/AB, AUUC246A/AB



2. OUTDOOR UNITS

Model No.: AUUH246A/AB, AUUC306A/AB, AUUH306A/AB



Parts List

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		AUUC186A	AUUC186AB	AUUH186A	AUUH186AB	
349480	ORIFICE	4948A20005A	4948A20005A	4948A20005A	4948A20005A	R
433501	GRILLE,DISCHARGE	3530A20007B	3530A20007B	3530A20007B	3530A20007B	R
437211	PANEL ASSY,FRONT	3721A20113A	3721A20113A	3721A20005Q	3721A20005Q	R
437212	PANEL ASSY,REAR	3721A20114A	3721A20114A	3720AP0003L	3720AP0003L	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681A20028P	4681A20028P	4681A20028P	4681A20028P	R
552112	TUBE ASSEMBLY,CONDENSER IN	5211A20765M	5211A20765M	5211A30298V	5211A30298V	R
552113	TUBE ASSEMBLY,CONDENSER OUT	5211A32003A	5211A32003A	5211A24003A	5211A24003A	R
552116	TUBE ASSEMBLY,REVERSING	-	-	5211A24005A	5211A24005A	R
561410	COIL ASSEMBLY,REVERSING VALVE	-	-	6141AR3733R	6141AR3733R	R
552117	TUBE ASSEMBLY,SUCTION	5211A33008A	5211A33008A	-	-	R
552203-1	VALVE,SERVICE	5220A20013A	5220A20013A	5220A20013A	5220A20013A	R
552203-2	VALVE,SERVICE	5220A20007A	5220A20007A	5220A20007A	5220A20007A	R
554031	CONDENSER ASSEMBLY,BENT	5403A20104C	5403A20104C	5403A20022R	5403A20022R	R
554160	COMPRESSOR ASSEMBLY	5416A90023A	5416A90023A	5416A90023A	5416A90023A	R
559010	FAN ASSEMBLY,PROPELLER	5901A10032A	5901A10032A	5901A10032A	5901A10032A	R
435511	COVER CONTROL	3551A30079A	3551A30079A	3551A30061G	3551A30061G	R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A20319G	4995A20319K	4995A10040U	4995A10040Y	R
268713	PWB(PCB) ASSY,SUB	-	6871A20130K	-	6871A20130K	R
669200	RELAY	6920AP3400A	6920AP3400A	6920AP3400A	6920AP3400A	R
W0CZZ	CAPACITOR,DRAWING	2A00986E	2A00986E	2A00986D	2A00986D	R
W0CZZ	CAPACITOR,DRAWING	-	-	2A00986X	2A00986X	R
268712	PWB(PCB) ASSY, DEICER	-	-	6871A20034A	6871A20034B	R
263230-1	THERMISTOR ASSEMBLY	-	-	3Q35015H	3Q35015H	R
263230-2	THERMISTOR ASSEMBLY	-	3Q35015S	-	3Q35015S	R
435512	COVER ASSEMBLY TOP	-	-	3H03266K	3H03266K	R
648600	CLAMP CAPACITOR	4H00442F	4H00442F	4H00442F	4H00442F	R
648600	CLAMP CAPACITOR	-	-	4H00930C	4H00930C	R


Parts List


LOCATION No.	DESCRIPTION	Part No.				REMARKS
		AUUC246A	AUUC246AB	AUUH246A	AUUH246AB	
137213-1	PANEL ASSEMBLY,SIDE	-	-	1A00202F	1A00202F	R
137213-2	PANEL ASSEMBLY,SIDE	-	-	3A02284Y	3A02284Y	R
437211	PANEL ASSY,FRONT	3721A20005Q	3721A20005Q	2A01041J	2A01041J	R
437212	PANEL ASSY,REAR	3720AP0003L	3720AP0003L	1A00208D	1A00208D	R
435512	COVER ASSY TOP	3H03266N	3H03266N	3H03266N	3H03266N	R
349480	ORIFICE	4948A20005A	4948A20005A	4948AP2527A	4948AP2527A	R
435301	GRILLE,DISCHARGE	3530A20007B	3530A20007B	3530A20007J	3530A20007J	R
435300	GRILLE,REAR	-	-	1A00208H	1A00208H	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681A20028P	4681A20028P	4681A20028P	4681A20028P	R
552112	TUBE ASSEMBLY,CONDENSER IN	-	-	5211A30298K	5211A30298K	R
552113	TUBE ASSEMBLY,CONDENSER OUT	5211A21128A	5211A21128A	5211A21133A	5211A21133A	R
552116	TUBE ASSEMBLY,REVERSING	-	-	5211A11001A	5211A11001A	R
548490	ACCUMULATOR ASSEMBLY(MECH)	4849A20036B	4849A20036B	-	-	R
552114	TUBE ASSEMBLY,DISCHARGE (OUTDOOR)	5211A21130A	5211A21130A	-	-	R
552202	VALVE,REVERSING	-	-	5220AR3228E	5220AR3228E	R
552203	VALVE,SERVICE	5220A20007A	5220A20007A	5220A20007A	5220A20007A	R
552203	VALVE,SERVICE	5220A20013A	5220A20013A	5220A20013A	5220A20013A	R
554031	CONDENSER ASSEMBLY,BENT	5403A20058D	5403A20058D	5403A10030A	5403A10030A	R
554160	COMPRESSOR ASSEMBLY	2520UXDP2BA	2520UXDP2BA	2520UXDP2BA	2520UXDP2BA	R
559010	FAN ASSEMBLY,PROPELLER	5901A10032A	5901A10032A	5901A10032A	5901A10032A	R
561410	COIL ASSEMBLY,REVERSING VALVE	-	-	6141AR3733R	6141AR3733R	R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A20319E	4995A20319H	4995A10040Q	4995A10040X	R
268713	PWB(PCB) ASSY,SUB	-	6871A20130K	-	6871A20130K	R
263230	THERMISTOR ASSEMBLY	-	-	3Q35015H	3Q35015H	R
263230-1	THERMISTOR ASSEMBLY	-	3Q35015S	-	3Q35015S	R
435512	COVER ASSEMBLY TOP	3551A30061G	3551A30061G	3551A30061K	3551A30061K	R
648600	CLAMP CAPACITOR	4H00442F	4H00442F	4H00442F	4H00442F	R
648600	CLAMP CAPACITOR	-	-	4H00930C	4H00930C	R
268711	PWB(PCB) ASSY,DEICER	-	-	6871A20034A	6871A20034A	R
669200	RELAY	6920AP3400A	6920AP3400A	6920AP3400A	6920AP3400A	R
W0CZZ	CAPACITOR,DRAWING	2A00986Y	2A00986Y	2A00986D	2A00986D	R
W0CZZ	CAPACITOR,DRAWING	-	-	2A00986X	2A00986X	R

Parts List

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		AUUC306A	AUUC306AB	AUUH306A	AUUH306AB	
137213-1	PANEL ASSEMBLY,SIDE	1A00202F	1A00202F	1A00202F	1A00202F	R
137213-2	PANEL ASSEMBLY,SIDE	3A02284Y	3A02284Y	3A02284Y	3A02284Y	R
349480	ORIFICE	4948AP2527A	4948AP2527A	4948AP2527A	4948AP2527A	R
435301	GRILLE,DISCHARGE	3530A20007J	3530A20007J	3530A20007J	3530A20007J	R
435511	COVER CONTROL	3551A30071Q	3551A30061G	3551A30071K	3551A30061G	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681A20028P	4681A20028P	4681A20028P	4681A20028P	R
552112	TUBE ASSEMBLY,CONDENSER IN	5211A30298K	5211A30298K	5211A30298K	5211A30298K	R
552113	TUBE ASSEMBLY,CONDENSER OUT	5211A21133C	5211A21133C	5211A21133B	5211A21133B	R
552116	TUBE ASSEMBLY,REVERSING	-	-	5211A11001B	5211A11001B	R
548490	ACCUMULATOR ASSEMBLY(MECH)	4849A22001C	4849A22001C	4849A22001B	4849A22001B	R
552570	MUFFLER ASSY	5257A22002C	5257A22002C	5257A22002B	5257A22002B	R
552202	VALVE,REVERSING	-	-	5220AR3228L	5220AR3228L	R
552203-1	VALVE,SERVICE	5220A20013A	5220A20013A	5220A20013A	5220A20013A	R
552203-2	VALVE,SERVICE	5220A20007A	5220A20007A	5220A20007A	5220A20007A	R
554031	CONDENSER ASSEMBLY,BENT	5403A10030A	5403A10030A	5403A10030A	5403A10030A	R
554160	COMPRESSOR ASSEMBLY	5416A90027A	5416A90027A	5416A90027A	5416A90027A	R
559010	FAN ASSEMBLY,PROPELLER	5901A10032A	5901A10032A	5901A10032A	5901A10032A	R
561410	COIL ASSEMBLY,REVERSING VALVE	-	-	6141AR3733R	6141AR3733R	R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A20319F	4995A20319J	4995A10040Q	4995A10040X	R
263230	THERMISTOR ASSEMBLY	-	-	3Q35015H	3Q35015H	R
263230-1	THERMISTOR ASSEMBLY	-	3Q35015S	-	3Q35015S	R
435512	COVER ASSEMBLY TOP	3H03266H	3H03266H	3H03266H	3H03266H	R
435300	GRILL REAR	1A00208H	1A00208H	1A00208H	1A00208H	R
268711	PWB(PCB) ASSY,DEICER	-	-	6871A20034A	6871A20034B	R
669200	RELAY	6920AP3400A	6920AP3400A	6920AP3400A	6920AP3400A	R
648600	CLAMP CAPACITOR	4H00442C	4H00442C	4H00442F	4H00442F	R
				4H00930C	4H00930C	
W6640	TERMINAL BLOCK	3A00093A	3A00093A	3A00093A	3A00093A	R
W0CZZ	CAPACITOR,DRAWING	2A00986Y	2A00986Y	2A00986D	2A00986D	R
W0CZZ	CAPACITOR,DRAWING	-	-	2A00986X	2A00986X	R
268713	PWB(PCB) ASSY, SUB	-	6871A20130K	-	6871A20130K	R

Model No.: AUUC368A/AB, AUUH368A/AB





Parts List

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		AUUC368A	AUUC368AB	AUUH368A	AUUH368AB	
137212	PANEL ASSEMBLY,SIDE	3721A10110A	3721A10110A	3721A10110A	3721A10110A	R
137213-2	PANEL ASSEMBLY,SIDE	3721A10111B	3721A10111B	3721A10111B	3721A10111B	R
435512	COVER ASSEMBLY TOP	3H03266H	3H03266H	3H03266H	3H03266H	R
437211	PANEL ASSY,FRONT	3721A10109A	3721A10109A	3721A10109A	3721A10109A	R
135301	GRILLE,DISCHARGE	3530A20006B	3530A20006B	3530A20006B	3530A20006B	R
135314	GRILLE,REAR	3530A10176B	3530A10176B	3530A10176B	3530A10176B	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681AR1392W	4681AR1392W	4681AR1392W	4681AR1392W	R
552112	TUBE ASSEMBLY,CONDENSER IN	5211A11010B	5211A11010B	5211A11010B	5211A11010B	R
552113	TUBE ASSEMBLY,CONDENSER OUT	5211A14004A	5211A14004A	5211A14004A	5211A14004A	R
552116	TUBE ASSEMBLY,REVERSING	5211A24008A	5211A24008A	5211A24008A	5211A24008A	R
552202	VALVE,REVERSING	3A02080E	3A02080E	3A02080E	3A02080E	R
552203-1	VALVE,SERVICE	5220A20013B	5220A20013B	5220A20013B	5220A20013B	R
552203-2	VALVE,SERVICE	5220A20007A	5220A20007A	5220A20007A	5220A20007A	R
554031	CONDENSER ASSEMBLY,BENT	5403A20168B	5403A20168B	5403A20168B	5403A20168B	R
554160	COMPRESSOR ASSEMBLY	2520UUCY2BA	2520UUCY2BA	2520UUCY2BA	2520UUCY2BA	R
559010	FAN ASSEMBLY,PROPELLER	5901A10033A	5901A10033A	5901A10033A	5901A10033A	R
561410	COIL ASSEMBLY,REVERSING VALVE	-	-	6141AR3733R	6141AR3733R	R
435511	COVER ASSEMBLY CONTROL	3551A10041B	-	3551A10041A	3551A10041C	R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	4995A20319P	4995A20319N	4995A20319M	4995A20319L	R
263230	THERMISTOR ASSEMBLY	-	-	3Q35015K	3Q35015K	R
548490	ACCUMULATOR ASSY(MECH)	4849A20001K	4849A20001K	4849A20001K	4849A20001K	R
263230-1	THERMIATOR ASSEMBLY	-	3H03266S	-	3H03266S	R
349480	ORIFICE	4948A20001A	4948A20001A	4948A20001A	4948A20001A	R
263230-1	THERMISTOR ASSEMBLY	-	3Q35015S	-	3Q35015S	R
268712	PWB(PCB) ASSY,DEICER	-	-	6871A20034A	6871A20034A	R
669200	RELAY	-	-	3A00261C	3A00261C	R
W0CZZ	CAPACITOR,DRAWING	3A02157A	3A02157A	3A02157A	3A02157A	R
268713	PWB(PCB)ASSY, SUB	-	6871A20130K	-	6871A20130K	R


Parts List

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		AUUC488A	AUUC488AB	AUUH488A	AUUH488AB	
137212	PANEL ASSEMBLY,SIDE	3720AP1215B	3720AP1215B	3720AP1215B	3720AP1215B	R
437212	PANEL ASSEMBLY,REAR	3720AP1202C	3720AP1202C	3720AP1202C	3720AP1202C	R
135301	GRILLE,DISCHARGE	3530AP1225D	3530AP1225D	3530AP1225D	3530AP1225D	R
435512	COVER ASSEMBLY TOP	3550AP1213B	3550AP1213B	3550AP1213B	3550AP1213B	R
435511	COVER ASSEMBLY CONTROL	3551A10041B	3551A10041B	3551A10041B	3551A10041B	R
437910	PANEL ASSY,FRONT	3720AP1212B	3720AP1212B	3720AP1212B	3720AP1212B	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681A20008R	4681A20008R	4681A20008R	4681A20008R	R
352111	TUBE ASSEMBLY,CONNECTOR	5211A11022A	5211A11022A	5211A11022A	5211A11022A	R
552115	TUBE ASSEMBLY MENI FOLD	5211A10166G	5211A10166G	5211A10166G	5211A10166G	R
552201	VALVE CHECK	3A01020D	3A01020D	3A01020D	3A01020D	R
552116	TUBE ASSEMBLY,REVERSING	5211A20269D	5211A20269D	5211A20269D	5211A20269D	R
548490	ACCUMULATOR ASSEMBLY	4849A20009H	4849A20009H	4849A20009H	4849A20009H	R
W5210B	TUBE CONNECTOR	5210AP7001R	5210AP7001R	5210AP7001R	5210AP7001R	R
552202	VALVE,REVERSING	3A02080B	3A02080B	3A02080B	3A02080B	R
552203-1	VALVE,SERVICE	5220A20001F	5220A20001F	5220A20001F	5220A20001F	R
552203-2	VALVE,SERVICE	2A00499L	2A00499L	2A00499L	2A00499L	R
554160	COMPRESSOR ASSEMBLY	2520UBAY2BA	2520UBAY2BA	2520UBAY2BA	2520UBAY2BA	R
554031-1	CONDENSER ASSEMBLY,BENT	5403A20193A	5403A20193A	5403A20193A	5403A20193A	R
554031-2	CONDENSER ASSEMBLY,BENT	5403A20193B	5403A20193B	5403A20193B	5403A20193B	R
559010	FAN ASSEMBLY,PROPELLER	1A00195B	1A00195B	1A00195B	1A00195B	R
561410	COIL ASSEMBLY,REVERSING VALVE	-	-	6141AR3733R	6141AR3733R	R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	6615AP2772Z	4995A10010S	4995A30011G	4995A10010J	R
263230	THERMISTOR ASSEMBLY	-	-	3Q35015H	3Q35015H	R
268712	PWB(PCB) ASSY,DEICER	-	-	6871A20034A	6871A20034A	R
566001	SWITCH MAGNET	2A01031K	2A01031K	2A01031K	2A01031K	R
W0CZZ	CAPACITOR,DRAWING	2A00986D	2A00986D	2A00986D	2A00986D	R
268713	PWB(PCB) ASSY,SUB	-	6871A20130K	-	6871A20130K	R


Parts List

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		AUUC608A	AUUC608AB	AUUH608A	AUUH608AB	
137213	PANEL ASSEMBLY,SIDE	3720AP1215B	3720AP1215B	3720AP1215B	3720AP1215B	R
437212	PANEL ASSEMBLY,REAR	3720AP1202C	3720AP1202C	3720AP1202C	3720AP1202C	R
135301	GRILLE,DISCHARGE	3530AP1225D	3530AP1225D	3530AP1225D	3530AP1225D	R
435512	COVER ASSEMBLY TOP	3550AP1213B	3550AP1213B	3550AP1213B	3550AP1213B	R
437910	PANEL ASSY,FRONT	3720AP1212B	3720AP1212B	3720AP1212B	3720AP1212B	R
546810	MOTOR ASSEMBLY,OUTDOOR	4681A20008R	4681A20008R	4681A20008R	4681A20008R	R
352111	TUBE ASSEMBLY,CONNECTOR	5211A11022B	5211A11022B	5211A11022B	5211A11022B	R
552115	TUBE ASSEMBLY MENI	5211A10166M	5211A10166M	5211A10166M	5211A10166M	R
552201	VALVE CHECK	3A01020D	3A01020D	3A01020D	3A01020D	R
552116	TUBE ASSEMBLY,REVERSING	5211A10391H	5211A10391H	5211A10391H	5211A10391H	R
552202	VALVE,REVERSING	3A02080B	3A02080B	3A02080B	3A02080B	R
552203-1	VALVE,SERVICE	5220A20006H	5220A20006H	5220A20006H	5220A20006H	R
552203-2	VALVE,SERVICE	2A00499L	2A00499L	2A00499L	2A00499L	R
554031-1	CONDENSER ASSEMBLY,BENT	5403A20193A	5403A20193A	5403A20193A	5403A20193A	R
554031-2	CONDENSER ASSEMBLY,BENT	5403A20193B	5403A20193B	5403A20193B	5403A20193B	R
554160	COMPRESSOR ASSEMBLY	5416A90026A	5416A90026A	5416A90026A	5416A90026A	R
559010	FAN ASSEMBLY,PROPELLER	1A00195B	1A00195B	1A00195B	1A00195B	R
561410	COIL ASSEMBLY,REVERSING VALVE	-	-	6141AR3733R	6141AR3733R	R
435511	COVER ASSEMBLY CONTROL	3A01293X	3A01293X	3A01293X	3A01293X	R
649950	CONTROL BOX ASSEMBLY,OUTDOOR	6615AP2772Z	L1995A10010S	4995A30011H	4995A10010L	R
263230	THERMISTOR ASSEMBLY	-	-	3Q35015H	3Q35015H	R
268712	PWB(PCB) ASSY,DEICER	-	-	6871A20034A	6871A20034A	R
669200	RELAY	-	-	3A00261C	3A00261C	R
648600	CLAMP CAPACITOR	4H00442B	4H00442B	4H00442B	4H00442B	R
W6640	TERMINAL BLOCK	3A00493A	3A00493A	3A00493A	3A00493A	R
W0CZZ	CAPACITOR,DRAWING	2A00986D	2A00986D	2A00986D	2A00986D	R
268713	PWB(PCB)ASSY, SUB	-	6871A20130K	-	6871A20130K	R


Model No.: PT-HEA/C, PT-CEA/C



Model No.: PT-HFA/C, PT-CFA/C



Model No.: PT-HDA/C, PT-CDA/C



Parts List

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		PT-CEA	PT-CEC	PT-HEA	PT-HEC	
137211	PANEL ASSEMBLY,FRONT(INDOOR)	3721A10105C	3721A10105D	3721A10105A	3721A10105B	R
135314	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A10059A	3531A10059A	3531A10059A	3531A10059A	R
135312	FILTER ASSY,AIR CLEANER	5231A10005A	5231A10005A	5231A10005A	5231A10005A	R
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	4681A20055A	4681A20055A	R
268712	PWB(PCB) ASSEMBLY,DISPLAY	6871A20096J	6871A20096J	6871A20096J	6871A20096J	R
135802	DOOR	3580A20005A	3580A20005A	3580A20005A	3580A20005A	R

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		PT-CFA	PT-CFC	PT-HFA	PT-HFC	
137211	PANEL ASSEMBLY,FRONT(INDOOR)	3721A10072B	3721A10072G	3721A10072A	3721A10072E	R
135314	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A10211A	3531A10211C	3531A10211A	3531A10211C	R
135312	FILTER ASSY,AIR CLEANER	5231A10012A	5231A10012A	5231A10012A	5231A10012A	R
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	4681A20055A	4681A20055A	R
268712	PWB(PCB) ASSEMBLY,DISPLAY	6871A20096J	6871A20096J	6871A20096J	6871A20096J	R

LOCATION No.	DESCRIPTION	Part No.				REMARKS
		PT-CDA	PT-CDC	PT-HDA	PT-HDC	
137211	PANEL ASSEMBLY,FRONT(INDOOR)	3721A10106C	3721A10106D	3721A10106A	3721A10106B	R
135314	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A10066A	3531A10066A	3531A10066A	3531A10066A	R
135312	FILTER ASSY,AIR CLEANER	5231A10004A	5231A10004A	5231A10004A	5231A10004A	R
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	4681A20055A	4681A20055A	R
268712	PWB(PCB) ASSEMBLY,DISPLAY	6871A20096J	6871A20096J	6871A20096J	6871A20096J	R
135802	DOOR	3580A20005A	3580A20005A	3580A20005A	3580A20005A	R